


2000-2003



**HONDA**

**SERVICE MANUAL**

**XR50R**





## HOW TO USE THIS MANUAL

This service manual describes the service procedures for the XR50R.

Follow the Maintenance Schedule (Section 3) recommendations to ensure that the vehicle is in peak operating condition and the emission levels are within the standards set by the California Air Resources Board.

Performing the first scheduled maintenance is very important. It compensates for the initial wear that occurs during the break-in period.

Sections 1 and 3 apply to the whole motorcycle. Section 2 illustrates procedures for removal/installation of components that may be required to perform service described in the following sections. Section 4 through 14 describe parts of the motorcycle, grouped according to location.

Find the section you want on this page, then turn to the table of contents on the first page of the section.

Most sections have an assembly or system illustration, service information and troubleshooting for the section.

The subsequent pages give detailed procedures.












If you do not know the source of the trouble, go to section 16, Troubleshooting.

## CONTENTS

	<b>GENERAL INFORMATION</b>	<b>1</b>
	<b>FRAME/BODY PANELS/EXHAUST SYSTEM</b>	<b>2</b>
	<b>MAINTENANCE</b>	<b>3</b>
<b>ENGINE AND DRIVE TRAIN</b>	<b>LUBRICATION SYSTEM</b>	<b>4</b>
	<b>FUEL SYSTEM</b>	<b>5</b>
	<b>ENGINE REMOVAL/INSTALLATION</b>	<b>6</b>
	<b>CYLINDER HEAD/VALVES</b>	<b>7</b>
	<b>CYLINDER/PISTON</b>	<b>8</b>
	<b>CLUTCH/GEARSHIFT LINKAGE</b>	<b>9</b>
	<b>ALTERNATOR/CAM CHAIN TENSIONER</b>	<b>10</b>
	<b>CRANKSHAFT/TRANSMISSION/KICKSTARTER</b>	<b>11</b>
<b>CHASSIS</b>	<b>FRONT WHEEL/BRAKE/SUSPENSION/STEERING</b>	<b>12</b>
	<b>REAR WHEEL/BRAKE/SUSPENSION</b>	<b>13</b>
<b>ELECTRICAL</b>	<b>IGNITION SYSTEM</b>	<b>14</b>
	<b>WIRING DIAGRAM</b>	<b>15</b>
	<b>TROUBLESHOOTING</b>	<b>16</b>
	<b>INDEX</b>	<b>17</b>

## SYMBOLS

The symbols used throughout this manual show specific service procedures. If supplementary information is required pertaining to these symbols, it would be explained specifically in the text without the use of the symbols.

	Replace the part(s) with new one(s) before assembly.
	Use recommended engine oil, unless otherwise specified.
	Use molybdenum oil solution (mixture of the engine oil and molybdenum grease in a ratio of 1:1).
	Use multi-purpose grease (lithium based multi-purpose grease NLGI # 2 or equivalent).
	Use molybdenum disulfide grease (containing more than 3 % molybdenum disulfide, NLGI # 2 or equivalent). Example: Molykote® BR-2 plus manufactured by Dow Corning, U. S. A. Multi-purpose M-2 manufactured by Mitsubishi Oil, Japan
	Use molybdenum disulfide paste (containing more than 40 % molybdenum disulfide, NLGI # 2 or equivalent). Example: Molykote® G-n paste, manufactured by Dow Corning, U. S. A. Honda Moly 60 (U. S. A. only) Rocol ASP manufactured by Rocol Limited, U. K. Rocol Paste manufactured by Sumico Lubricant, Japan
	Use silicone grease.
	Apply a locking agent. Use a medium strength locking agent unless otherwise specified.
	Apply sealant.
	Use DOT 4 brake fluid. Use the recommended brake fluid unless otherwise specified.
	Use fork or suspension fluid.

# 1. GENERAL INFORMATION

GENERAL SAFETY	1-1	TOOLS	1-12
SERVICE RULES	1-2	LUBRICATION & SEAL POINTS	1-13
MODEL IDENTIFICATION	1-3	CABLE & HARNESS ROUTING	1-14
SPECIFICATIONS	1-4	EMISSION CONTROL SYSTEMS	1-17
TORQUE VALUES	1-10	EMISSION CONTROL INFORMATION LABEL (Except Canada type)	1-18

## GENERAL SAFETY

### CARBON MONOXIDE

If the engine must be running to do some work, make sure the area is well ventilated. Never run the engine in an enclosed area.

#### ▲WARNING

*The exhaust contains poisonous carbon monoxide gas that can cause loss of consciousness and may lead to death.*

Run the engine in an open area or with an exhaust evacuation system in an enclosed area.

### GASOLINE

Work in a well ventilated area. Keep cigarettes, flames or sparks away from the work area or where gasoline is stored.

#### ▲WARNING

*Gasoline is extremely flammable and is explosive under certain conditions. KEEP OUT OF REACH OF CHILDREN.*

### HOT COMPONENTS

#### ▲WARNING

*Engine and exhaust system parts become very hot and remain hot for some time after the engine is run. Wear insulated gloves or wait until the engine and exhaust system have cooled before handling these parts.*

### USED ENGINE OIL

#### ▲WARNING

*Used engine oil may cause skin cancer if repeatedly left in contact with the skin for prolonged periods. Although this is unlikely unless you handle used oil on a daily basis, it is still advisable to thoroughly wash your hands with soap and water as soon as possible after handling used oil. KEEP OUT OF REACH OF CHILDREN.*



## GENERAL INFORMATION

---


### SERVICE RULES

1. Use genuine HONDA or HONDA-recommended parts and lubricants or their equivalents. Parts that don't meet HONDA's design specifications may cause damage to the motorcycle.
2. Use the special tools designed for this product to avoid damage and incorrect assembly.
3. Use only metric tools when servicing the motorcycle. Metric bolts, nuts and screws are not interchangeable with English fasteners.
4. Install new gaskets, O-rings, cotter pins, and lock plates when reassembling.
5. When tightening bolts or nuts, begin with the larger diameter or inner bolt first. Then tighten to the specified torque diagonally in incremental steps unless a particular sequence is specified.
6. Clean parts in cleaning solvent upon disassembly. Lubricate any sliding surfaces before reassembly.
7. After reassembly, check all parts for proper installation and operation.
8. Route all electrical wires as shown on pages 1-14 through 1-16, Cable and Harness Routing.


## MODEL IDENTIFICATION



- (1) The frame serial number is stamped on the left side of the steering head.




- (2) The engine serial number is stamped on the lower left of the crankcase.



- (3) The Vehicle Identification Number (VIN) is located on right side of the steering head on the Safety Certification Label.



- (4) The carburetor identification number is stamped on the left side of the carburetor body as shown.



- (5) The color label is attached on the left side of the main frame. When ordering color-coded parts, always specify the designated color code.

## GENERAL INFORMATION

### SPECIFICATIONS

GENERAL		
	ITEM	SPECIFICATIONS
DIMENSIONS	Overall length	1,305 mm (51.4 in)
	Overall width	583 mm (23.0 in)
	Overall height	780 mm (30.7 in)
	Wheelbase	915 mm (36.0 in)
	Seat height	550 mm (21.7 in)
	Footpeg height	215 mm (8.5 in)
	Ground clearance	150 mm (5.9 in)
	Dry weight	47 kg (104 lbs)
	Curb weight	50 kg (110 lbs)
	Maximum weight capacity	40 kg (88 lbs)
	FRAME	Frame type
Front suspension		Telescopic fork
Front wheel travel		87 mm (3.4 in)
Rear suspension		Swingarm
Rear wheel travel		70 mm (2.8 in)
Rear damper		Conventional type oil damper
Front tire size		2.50-10 33J
Rear tire size		2.50-10 33J
Tire brand		CHENG SHIN
Front brake		Internal expanding shoe
Rear brake		Internal expanding shoe
Caster angle		25°30'
Trail length		35 mm (1.4 in)
Fuel tank capacity		3.0 l (0.79 US gal , 0.66 Imp gal)
Fuel tank reserve capacity		0.9 l (0.24 US gal , 0.20 Imp gal)
ENGINE	Bore and stroke	39.0 × 41.4 mm (1.54 × 1.63 in)
	Displacement	49 cm <sup>3</sup> (3.0 cu-in)
	Compression ratio	10.0 : 1
	Valve train	Chain driven OHC with rocker arm
	Intake valve	opens at 1 mm
		closes (0.04 in)
	Exhaust valve	opens lift
		closes
	Lubrication system	Forced pressure and wet sump
	Oil pump type	Trochoid
	Cooling system	Air cooled
Air filtration	Oiled polyurethane foam	
Crankshaft type	Assembled type	
Engine dry weight	17.2 kg (37.9 lbs)	
Cylinder arrangement	Single cylinder inclined 80° from vertical	

GENERAL (Cont'd)		
	ITEM	SPECIFICATIONS
CARBURETOR	Carburetor type Throttle bore	Piston valve 13 mm (0.5 in)
DRIVE TRAIN	Clutch system Clutch operation system Transmission Primary reduction Final reduction Gear ratio  Gearshift pattern	Multi-plate, wet Automatic centrifugal 3-speed 4.058 (69/17) 2.642 (37/14) 1st 3.272 (36/11) 2nd 1.667 (25/15) 3rd 1.190 (25/21) Left foot operated, return system, N-1-2-3
ELECTRICAL	Ignition system Starting system	CDI (Capacitive Discharge Ignition) Kickstarter

## GENERAL INFORMATION

Unit: mm (in)

LUBRICATION SYSTEM		STANDARD	SERVICE LIMIT
ITEM			
Engine oil capacity	At draining	0.6 l (0.6 US qt, 0.5 Imp qt)	————
	At disassembly	0.8 l (0.8 US qt, 0.7 Imp qt)	————
Recommended engine oil		HONDA GN4 4-stroke oil or equivalent motor oil API service classification SF or SG Viscosity: SAE 10W-30	————
Oil pump rotor	Tip clearance	0.15 (0.006)	0.20 (0.008)
	Body clearance	0.02–0.07 (0.001–0.003)	0.12 (0.005)
	Side clearance	0.10–0.15 (0.004–0.006)	0.20 (0.008)

FUEL SYSTEM	SPECIFICATIONS
ITEM	
Carburetor identification number	PA42A
Main jet	# 58
Slow jet	# 35 × # 35
Jet needle clip position	2nd groove from top
Air screw initial opening	1-1/2 turns out
Float level	12.7 mm (0.50 in)
Idle speed	1,700 ± 100 rpm
Throttle grip free play	2.0–4.0 mm (1/16–3/16 in)

Unit: mm (in)

CYLINDER HEAD/VALVES			STANDARD	SERVICE LIMIT
ITEM				
Cylinder compression			981–1,177 kPa (10.0–12.0 kgf/cm <sup>2</sup> , 142–171 psi) at 1,000 rpm	————
Cylinder head warpage			————	0.05 (0.002)
Valve, valve guide	Valve clearance	IN	0.05 ± 0.02 (0.002 ± 0.001)	————
		EX	0.05 ± 0.02 (0.002 ± 0.001)	————
	Valve stem O.D.	IN	4.970–4.985 (0.1957–0.1963)	4.92 (0.194)
		EX	4.955–4.970 (0.1951–0.1957)	4.92 (0.194)
	Valve guide I.D.	IN/EX	5.000–5.012 (0.1969–0.1973)	5.03 (0.198)
	Stem-to-guide clearance	IN	0.015–0.042 (0.0006–0.0017)	0.08 (0.003)
EX		0.030–0.057 (0.0012–0.0022)	0.10 (0.004)	
Valve seat width		IN/EX	1.0–1.3 (0.04–0.05)	2.0 (0.08)
Valve spring free length			IN/EX	33.34 (1.313)
Rocker arm/shaft	Rocker arm I.D.	IN/EX	10.000–10.015 (0.3937–0.3943)	10.10 (0.398)
	Rocker arm shaft O.D.	IN/EX	9.978–9.987 (0.3928–0.3932)	9.91 (0.390)
Camshaft	Cam lobe height	IN	20.003–20.123 (0.7875–0.7922)	19.66 (0.774)
		EX	19.994–20.114 (0.7872–0.7919)	19.65 (0.774)

## GENERAL INFORMATION

Unit: mm (in)

CYLINDER/PISTON		ITEM		STANDARD	SERVICE LIMIT	
Cylinder	I.D.			39.005 – 39.015 (1.5356 – 1.5360)	39.05 (1.537)	
	Out of round			_____	0.10 (0.004)	
	Taper			_____	0.10 (0.004)	
	Warpage			_____	0.05 (0.002)	
Piston, piston rings	Piston mark direction			"IN" mark facing toward the intake side	_____	
	Piston O.D.			38.975 – 38.995 (1.5344 – 1.5352)	38.90 (1.531)	
	Piston O.D. measurement point			8 mm (0.3 in) from bottom of skirt	_____	
	Piston pin bore I.D.			13.002 – 13.008 (0.5119 – 0.5121)	13.06 (0.514)	
	Piston pin O.D.			12.994 – 13.000 (0.5116 – 0.5118)	12.98 (0.511)	
	Piston-to-piston pin clearance			0.002 – 0.014 (0.0001 – 0.0006)	0.08 (0.003)	
	Piston ring-to-ring groove clearance	Top/Second			0.015 – 0.050 (0.0006 – 0.0020)	0.12 (0.005)
		Piston ring end gap				
		Top			0.05 – 0.15 (0.002 – 0.006)	0.5 (0.02)
		Second			0.05 – 0.20 (0.002 – 0.008)	0.5 (0.02)
	Oil (side rail)			0.3 – 0.9 (0.01 – 0.04)	1.1 (0.04)	
Cylinder-to-piston clearance				0.010 – 0.040 (0.0004 – 0.0016)	0.15 (0.006)	
Connecting rod small end I.D.				13.016 – 13.034 (0.5124 – 0.5131)	13.08 (0.515)	
Connecting rod-to-piston pin clearance				0.016 – 0.040 (0.0006 – 0.0016)	0.12 (0.005)	

Unit: mm (in)

CLUTCH/GEARSHIFT LINKAGE		ITEM		STANDARD	SERVICE LIMIT
Clutch disc thickness	A			2.52 – 2.68 (0.099 – 0.106)	2.3 (0.09)
	B			3.32 – 3.48 (0.131 – 0.137)	3.0 (0.12)
Clutch plate warpage				_____	0.20 (0.008)
Centrifugal clutch spring free length				22.4 (0.88)	19.4 (0.76)
Primary drive gear I.D.				21.000 – 21.021 (0.8268 – 0.8276)	21.05 (0.829)
Clutch center guide	I.D.			16.988 – 17.006 (0.6688 – 0.6695)	17.04 (0.671)
	O.D.			20.930 – 20.950 (0.8240 – 0.8248)	20.90 (0.823)
Crankshaft O.D. at clutch center guide				16.966 – 16.984 (0.6680 – 0.6687)	16.90 (0.665)

Unit: mm (in)

ALTERNATOR/CAM CHAIN TENSIONER		ITEM		STANDARD	SERVICE LIMIT
Cam chain tensioner	Push rod O.D.			11.985 – 12.000 (0.4718 – 0.4724)	11.94 (0.470)
	Spring free length			111.3 (4.38)	100 (3.9)

## GENERAL INFORMATION

Unit: mm (in)

CRANKSHAFT/TRANSMISSION/KICKSTARTER			STANDARD	SERVICE LIMIT	
ITEM					
Crankshaft	Side clearance		0.010 – 0.350 (0.0004 – 0.0138)	0.60 (0.024)	
	Radial clearance		0 – 0.012 (0 – 0.0005)	0.05 (0.002)	
	Runout			0.10 (0.004)	
Transmission	Gear I.D.	M2	17.016 – 17.043 (0.6699 – 0.6710)	17.10 (0.673)	
		C1	23.020 – 23.053 (0.9063 – 0.9076)	23.10 (0.909)	
		C3	20.020 – 20.053 (0.7882 – 0.7895)	20.10 (0.791)	
	Bushing O.D.		C1	22.979 – 23.000 (0.9047 – 0.9055)	22.93 (0.903)
	Bushing I.D.		C1	20.000 – 20.021 (0.7874 – 0.7882)	20.08 (0.791)
	Gear-to-bushing clearance		C1	0.020 – 0.074 (0.0008 – 0.0029)	0.10 (0.004)
	Mainshaft O.D.		M2	16.966 – 16.984 (0.6680 – 0.6687)	16.95 (0.667)
	Countershaft O.D.		C1	19.959 – 19.980 (0.7858 – 0.7866)	19.94 (0.785)
	Gear-to-shaft clearance		M2	0.032 – 0.077 (0.0013 – 0.0030)	0.10 (0.004)
Gear bushing-to-shaft clearance		C1	0.020 – 0.062 (0.0008 – 0.0024)	0.10 (0.004)	
Shift fork	I.D.		34.075 – 34.100 (1.3415 – 1.3425)	34.14 (1.344)	
	Claw thickness		4.86 – 4.94 (0.191 – 0.194)	4.60 (0.181)	
	Shift drum O.D.		33.950 – 33.975 (1.3366 – 1.3376)	33.93 (1.336)	

## GENERAL INFORMATION

Unit: mm(in)

FRONT WHEEL/BRAKE/SUSPENSION/STEERING			
ITEM		STANDARD	SERVICE LIMIT
Minimum tire tread depth		_____	3.0 (0.12)
Cold tire pressure		100 kPa (1.0 kgf/cm <sup>2</sup> , 15 psi)	_____
Axle runout		_____	0.20 (0.008)
Wheel rim-to-hub distance		6.3 ± 1.0 (0.25 ± 0.04)	_____
Wheel rim runout	Radial	_____	2.0 (0.08)
	Axial	_____	2.0 (0.08)
Brake	Brake lever free play	10–20 (3/8–13/16)	_____
	Brake drum I.D.	80 (3.1)	80.5 (3.17)
	Brake lining thickness	3.5 (0.14)	2.0 (0.08)
Fork	Spring free length	160.8 (6.33)	158.3 (6.23)

Unit: mm(in)

REAR WHEEL/BRAKE/SUSPENSION			
ITEM		STANDARD	SERVICE LIMIT
Minimum tire tread depth		_____	3.0 (0.12)
Cold tire pressure		125 kPa (1.25 kgf/cm <sup>2</sup> , 18 psi)	_____
Axle runout		_____	0.20 (0.008)
Wheel rim-to-hub distance		25 ± 1.0 (1.0 ± 0.04)	_____
Wheel rim runout	Radial	_____	2.0 (0.08)
	Axial	_____	2.0 (0.08)
Drive chain	Size/link	DID420MBK1/78	_____
	Slack	15–25 (9/16–1)	_____
Brake	Brake pedal free play	10–20 (3/8–13/16)	_____
	Brake drum I.D.	80 (3.1)	80.5 (3.17)
	Brake lining thickness	3.5 (0.14)	2.0 (0.08)

IGNITION SYSTEM		SPECIFICATIONS	
ITEM			
Spark plug	Standard	CR6HSA (NGK)	U20FSR-U (DENSO)
	For cold climate/below 41°F/5°C	CR5HSA (NGK)	U16FSR-U (DENSO)
	For extended high speed riding	CR7HSA (NGK)	U22FSR-U (DENSO)
Spark plug gap		0.60–0.70 mm (0.024–0.028 in)	
Ignition coil peak voltage		100 V minimum	
Ignition pulse generator peak voltage		0.7 V minimum	
Alternator exciter coil peak voltage		100 V minimum	
Ignition timing ("F" mark)		27°BTDC at idle	

## GENERAL INFORMATION

### TORQUE VALUES

STANDARD			
FASTENER TYPE	TORQUE N-m (kgf-m, lbf-ft)	FASTENER TYPE	TORQUE N-m (kgf-m, lbf-ft)
5 mm hex bolt and nut	5 (0.5 , 3.6)	5 mm screw	4 (0.4 , 2.9)
6 mm hex bolt and nut	10 (1.0 , 7)	6 mm screw	9 (0.9 , 6.5)
8 mm hex bolt and nut	22 (2.2 , 16)	6 mm flange bolt (8 mm head, small flange)	10 (1.0 , 7)
10 mm hex bolt and nut	34 (3.5 , 25)	6 mm flange bolt (8 mm head, large flange)	12 (1.2 , 9)
12 mm hex bolt and nut	54 (5.5 , 40)	6 mm flange bolt (10 mm head) and nut	12 (1.2 , 9)
		8 mm flange bolt and nut	26 (2.7 , 20)
		10 mm flange bolt and nut	39 (4.0 , 29)

- Torque specifications listed below are for important fasteners.
- Others should be tightened to standard torque values listed above.

NOTES: 1. Apply oil to the threads.  
2. Apply grease to the seating surface.  
3. U-nut.  
4. ALOC bolt; replace with a new one.

ENGINE				
ITEM	Q'TY	THREAD DIA. (mm)	TORQUE N-m (kgf-m, lbf-ft)	REMARKS
<b>MAINTENANCE:</b>				
Spark plug	1	10	12 (1.2 , 9)	
Oil drain bolt	1	12	25 (2.5 , 18)	
Valve adjuster hole cap	2	30	12 (1.2 , 9)	NOTE 1
Valve adjuster lock nut	2	5	9 (0.9 , 6.5)	
Clutch adjuster lock nut	1	8	12 (1.2 , 9)	
<b>LUBRICATION SYSTEM:</b>				
Oil pump mounting screw	3	6	8 (0.8 , 5.8)	
Oil pump cover screw	3	5	5 (0.5 , 3.6)	
<b>ENGINE REMOVAL/INSTALLATION:</b>				
Drive sprocket fixing plate bolt	2	6	12 (1.2 , 9)	
<b>CYLINDER HEAD/VALVES:</b>				
Cylinder head nut	4	6	11 (1.1 , 8)	
Cylinder head right side cover bolt	2	6	10 (1.0 , 7)	
Cam sprocket bolt	2	5	9 (0.9 , 6.5)	
<b>CYLINDER/PISTON:</b>				
Cam chain guide roller pin bolt	1	8	10 (1.0 , 7)	
<b>CLUTCH/GEARSHIFT LINKAGE:</b>				
Clutch outer cover screw	4	5	5 (0.5 , 3.6)	
Clutch lock nut	1	14	42 (4.3 , 31)	
Clutch assembly screw	4	5	6 (0.6 , 4.3)	
Shift drum stopper arm bolt	1	6	13 (1.3 , 9)	
Shift return spring pin	1	8	29 (3.0 , 22)	
Gearshift cam plate bolt	1	6	17 (1.7 , 12)	
<b>ALTERNATOR/CAM CHAIN TENSIONER:</b>				
Flywheel nut	1	10	41 (4.2 , 30)	
Cam chain tensioner sealing bolt	1	14	23 (2.3 , 17)	
Cam chain tensioner pivot bolt	1	8	16 (1.6 , 12)	
<b>CRANKSHAFT/TRANSMISSION/KICKSTARTER:</b>				
Shift drum bolt	1	6	12 (1.2 , 9)	

**GENERAL INFORMATION**

<b>FRAME</b>				
ITEM	Q'TY	THREAD DIA. (mm)	TORQUE N·m (kgf·m, lbf·ft)	REMARKS
<b>FRAME/BODY PANELS/EXHAUST SYSTEM:</b>				
Side stand pivot bolt	1	10	—	page 2-5
Muffler mounting bolt	1	8	26 (2.7, 20)	
Exhaust pipe protector bolt	3	6	15 (1.5, 11)	
Exhaust pipe cover screw	4	5	6 (0.6, 4.3)	
<b>MAINTENANCE:</b>				
Fuel valve mounting bolt	2	6	9 (0.9, 6.5)	
<b>FUEL SYSTEM:</b>				
Connecting tube band screw	1	4	1 (0.1, 0.7)	
<b>ENGINE REMOVAL/INSTALLATION:</b>				
Engine hanger nut	2	8	31 (3.2, 23)	
<b>FRONT WHEEL/BRAKE/SUSPENSION/STEERING:</b>				
Handlebar mounting nut	2	8	20 (2.0, 14)	
Engine stop switch/throttle housing screw	2	5	3 (0.3, 2.2)	
Brake lever pivot bolt	1	5	3 (0.3, 2.2)	
Brake lever pivot nut	1	5	3 (0.3, 2.2)	
Spoke nipple	28	BC 2.3	2 (0.2, 1.4)	
Front axle nut	1	12	47 (4.8, 35)	NOTE 3
Front brake arm pinch bolt	1	5	6 (0.6, 4.3)	NOTE 4
Fork protector bolt	4	6	10 (1.0, 7)	
Steering stem nut	1	22	74 (7.5, 54)	
Steering stem top thread	1	22	—	page 12-17
<b>REAR WHEEL/BRAKE/SUSPENSION:</b>				
Spoke nipple	28	BC 2.3	2 (0.2, 1.4)	
Rear axle nut	1	12	47 (4.8, 35)	NOTE 3
Driven sprocket nut	4	8	32 (3.3, 24)	NOTE 3
Rear brake arm pinch bolt	1	5	6 (0.6, 4.3)	NOTE 4
Swingarm pivot nut	1	10	39 (4.0, 29)	NOTE 2,3
Shock absorber mounting nut	2	10	34 (3.5, 25)	NOTE 3
Drive chain slider nut	1	6	12 (1.2, 9)	NOTE 3
<b>IGNITION SYSTEM:</b>				
Ignition coil mounting bolt	1	5	6 (0.6, 4.3)	

## GENERAL INFORMATION


### TOOLS



- NOTES: 1. Equivalent commercially available in U.S.A.  
 2. Not available in U.S.A.  
 3. Alternative tool.

DESCRIPTION	TOOL NUMBER	REMARKS	REF. SEC.
Carburetor float level gauge	07401-0010000		5
Spoke wrench, 4.1 × 4.5 mm	07701-0020100	NOTE 1	3,12,13
Pin spanner	07702-0020001		12
Valve adjusting wrench, 8 × 9 mm	07708-0030100	NOTE 1	3
Valve adjuster B	07708-0030400	NOTE 3: 07908-KE90200 (U.S.A. only)	3
Lock nut wrench, 20 × 24 mm	07716-0020100		9
Extension bar	07716-0020500	NOTE 1	9
Universal holder	07725-0030000		10
Flywheel holder	07725-0040000	NOTE 1	9
Attachment, 32 × 35 mm	07746-0010100		12, 13
Attachment, 37 × 40 mm	07746-0010200		11, 12
Pilot, 12 mm	07746-0040200		12, 13
Pilot, 17 mm	07746-0040400		11
Bearing remover shaft	07746-0050100	NOTE 1	12, 13
Bearing remover head, 12 mm	07746-0050300	NOTE 1	12, 13
Driver	07749-0010000		11, 12, 13
Valve spring compressor	07757-0010000		7
Valve seat cutter		NOTE 1	7
Seat cutter, 24 mm (45° IN)	07780-0010600		
Seat cutter, 20.5 mm (45° EX)	07780-0011000		
Flat cutter, 24 mm (32° IN)	07780-0012500		
Flat cutter, 21.5 mm (32° EX)	07780-0012800		
Interior cutter, 22 mm (60° IN/EX)	07780-0014202		
Cutter holder, 5 mm	07781-0010400		
Flywheel puller	07933-GE00000	NOTE 2, 3: 07933-0010000	10
Valve guide driver, 5.0 mm	07942-MA60000		7
Ball race remover	07944-1150001		12
Steering stem driver	07946-GC40000	NOTE 3: 07946-MB00000 07946-GC4000A (U.S.A. only)	12
Valve spring compressor attachment	07959-KM30101		7
Valve guide reamer, 5.0 mm	07984-MA60001	NOTE 3: 07984-MA6000C (U.S.A. only)	7
Peak voltage adaptor	07HGJ-0020100	NOTE 3 Peak voltage tester (U.S.A. only)	14




CABLE & HARNESS ROUTING





**GENERAL INFORMATION**

---



## EMISSION CONTROL SYSTEMS

The California Air Resources Board (CARB) requires manufacturers to certify that their motorcycles comply with applicable exhaust emissions standards during their useful life, when operated and maintained according to the instructions provided.

### SOURCE OF EMISSIONS

The combustion process produces carbon monoxide and hydrocarbons. Controlling hydrocarbon emissions is very important because, under certain conditions, they react to form photochemical smog when subjected to sunlight. Carbon monoxide does not react in the same way, but it is toxic.


Honda Motor Co., Ltd. utilizes lean carburetor settings as well as other systems, to reduce carbon monoxide and hydrocarbons.

### EXHAUST EMISSION CONTROL SYSTEM

The exhaust emission control system is composed of a lean carburetor setting, and no adjustments should be made except idle speed adjustment with the throttle stop screw. The exhaust emission control system is separate from the crankcase emission control system.

### CRANKCASE EMISSION CONTROL SYSTEM

The engine is equipped with a closed crankcase system to prevent discharging crankcase emissions into the atmosphere. Blow-by gas is returned to the combustion chamber through the air cleaner and carburetor.




## GENERAL INFORMATION

---

### EMISSION CONTROL INFORMATION LABEL (Except Canada type)

The Vehicle Emission Control Information Label is attached on the reverse side of the left fuel tank shroud.



EMISSION CONTROL INFORMATION LABEL

# 2. FRAME/BODY PANELS/EXHAUST SYSTEM

SERVICE INFORMATION	2-1	NUMBER PLATE	2-3
TROUBLESHOOTING	2-1	FRONT FENDER	2-3
SEAT	2-2	EXHUST SYSTEM	2-4
FUEL TANK	2-3	SIDE STAND	2-5

## SERVICE INFORMATION

### GENERAL

#### ▲ WARNING

- *Gasoline is extremely flammable and is explosive under certain conditions. KEEP OUT OF REACH OF CHILDREN.*
- *Serious burns may result if the exhaust system is not allowed to cool before components are removed or serviced.*

- Work in a well ventilated area. Smoking or allowing flames or sparks in the work area or where gasoline is stored can cause a fire or explosion.
- This section covers removal and installation of the body panels, fuel tank and exhaust system.
- Always replace the exhaust pipe gasket after removing the exhaust system from the engine.
- When installing the exhaust system, loosely install all of the fasteners. Always tighten the exhaust pipe joint nuts first, then tighten the mounting fastener. If you tighten the mounting fasteners first, the exhaust pipe may not seat properly.
- Always inspect the exhaust system for leaks after installation.

### TORQUE VALUES

Side stand pivot bolt	See page 2-5
Muffler mounting bolt	26 N·m (2.7 kgf·m , 20 lbf·ft)
Exhaust pipe protector bolt	15 N·m (1.5 kgf·m , 11 lbf·ft)
Exhaust pipe cover screw A	6 N·m (0.6 kgf·m , 4.3 lbf·ft)
Exhaust pipe cover screw B	6 N·m (0.6 kgf·m , 4.3 lbf·ft)

## TROUBLESHOOTING

#### Excessive exhaust noise

- Broken exhaust system
- Exhaust gas leak

#### Poor performance

- Deformed exhaust system
- Exhaust gas leak
- Clogged muffler

## SEAT

### REMOVAL


Remove the two trim clips.  
Remove the two screws and bolts.

Pull the seat assembly back and remove it.


### INSTALLATION

Install the seat assembly by inserting the prongs into the retainers on the frame.

Install the bolts and screws and tighten them.  
Install the trim clips and lock them by pushing the center pin flush.



### DISASSEMBLY/ASSEMBLY



## FUEL TANK

**⚠WARNING**

*Gasoline is extremely flammable and is explosive under certain conditions. KEEP OUT OF REACH OF CHILDREN.*


Remove the seat assembly (page 2-2).

Remove the breather tube from the number plate. Turn the fuel valve OFF and disconnect the fuel tube from the fuel valve.

Remove the two bolts, washer and collar. Remove the fuel tank.

*For fuel strainer service, see page 3-4.*

Installation is in the reverse order of removal.




## NUMBER PLATE

Remove the breather tube from the number plate. Remove the fender mounting bolt.

Remove the number plate from the steering stem nut and front fender.


Installation is in the reverse order of removal.



## FRONT FENDER

Remove the three bolts and the front fender.

Installation is in the reverse order of removal.



## EXHAUST SYSTEM

**⚠WARNING**

*Serious burns may result if the exhaust system is not allowed to cool before components are removed or serviced.*

For spark  
arrester maintenance,  
refer to  
page 3-17

### REMOVAL

Remove the seat assembly (page 2-2).

Remove the exhaust pipe joint nuts.  
Remove the mounting bolt and the muffler.  
Remove the exhaust pipe joint gasket.

### INSTALLATION


Install a new joint gasket into the exhaust port.  
Set the exhaust pipe onto the engine by aligning the exhaust pipe flange with the cylinder head studs, then install the joint nuts and the mounting bolt.

Tighten the joint nuts.

Tighten the mounting bolt.

**TORQUE:** 26 N·m (2.7 kgf·m , 20 lbf·ft)

Install the seat assembly (page 2-2).



## SIDE STAND

### REMOVAL

Support the motorcycle securely with a hoist or equivalent.

Retract the side stand and remove the following:

- return spring
- pivot nut
- pivot bolt
- side stand

### INSTALLATION

Apply grease to the side stand pivot and sliding surfaces.

Install the side stand with the pivot bolt.

Tighten the pivot bolt.



**TORQUE:** 10 N·m (1.0 kgf·m , 7 lbf·ft)

Loosen the pivot bolt 45–90°.

Install the pivot nut and tighten it while holding the pivot bolt.

Install the return spring as shown.

Check the side stand operation for freedom of movement.



---

**MEMO**

# 3. MAINTENANCE

SERVICE INFORMATION	3-1	DRIVE CHAIN	3-12
MAINTENANCE SCHEDULE	3-3	DRIVE CHAIN SLIDER	3-14
FUEL LINE	3-4	BRAKE SHOE WEAR	3-14
THROTTLE OPERATION	3-4	BRAKE SYSTEM	3-14
AIR CLEANER	3-5	CLUTCH SYSTEM	3-16
SPARK PLUG	3-6	SIDE STAND	3-16
VALVE CLEARANCE	3-7	SUSPENSION	3-16
ENGINE OIL	3-8	SPARK ARRESTER	3-17
ENGINE OIL STRAINER SCREEN	3-10	NUTS, BOLTS, FASTENERS	3-18
ENGINE OIL CENTRIFUGAL FILTER	3-10	WHEELS/TIRES	3-18
ENGINE IDLE SPEED	3-11	STEERING HEAD BEARINGS	3-19

## SERVICE INFORMATION

### GENERAL

#### ▲WARNING

- Gasoline is extremely flammable and is explosive under certain conditions. Work in a well ventilated area. Smoking or allowing flames or sparks in the work area or where the gasoline is stored can cause a fire or explosion.
- When the engine must be running to do some work, make sure the area is well-ventilated. Never run the engine in an enclosed area. The exhaust contains poisonous carbon monoxide gas that may cause loss of consciousness and lead to death. Run the engine in an open area or with an exhaust evacuation system in an enclosed area.

- Place the motorcycle on a level ground before starting any work.

### SPECIFICATIONS

ITEM		SPECIFICATIONS	
Spark plug	Standard	CR6HSA (NGK)	U20FSR-U (DENSO)
	For cold climate/below 41°F/5°C	CR5HSA (NGK)	U16FSR-U (DENSO)
	For extended high speed riding	CR7HSA (NGK)	U22FSR-U (DENSO)

## MAINTENANCE

ITEM		SPECIFICATIONS	
Engine oil capacity	At draining	0.6 l (0.6 US qt, 0.5 Imp qt)	
	At disassembly	0.8 l (0.8 US qt, 0.7 Imp qt)	
Recommended engine oil		HONDA GN4 4-stroke oil or equivalent motor oil API service classification SF or SG Viscosity: SAE 10W-30	
Engine idle speed		1,700 ± 100 rpm	
Throttle grip free play		2.0–4.0 mm (1/16–3/16 in)	
Valve clearance	IN	0.05 ± 0.02 mm (0.002 ± 0.001 in)	
	EX	0.05 ± 0.02 mm (0.002 ± 0.001 in)	
Drive chain slack		15–25 mm (5/8–1 in)	
Drive chain size/link		DID420MBK1/78	
Brake lever free play		10–20 mm (3/8–13/16 in)	
Brake pedal free play		10–20 mm (3/8–13/16 in)	
Tire size	Front	2.50-10 33J	
	Rear	2.50-10 33J	
Tire brand	CHENG SHIN	Front	C-183A
		Rear	C-183A
Tire air pressure	Front	100 kPa (1.0 kgf/cm <sup>2</sup> , 15 psi)	
	Rear	125 kPa (1.25 kgf/cm <sup>2</sup> , 18 psi)	
Minimum tire tread depth	Front	3.0 mm (0.12 in)	
	Rear	3.0 mm (0.12 in)	

## TORQUE VALUES

Fuel valve mounting bolt	9 N·m (0.9 kgf·m, 6.5 lbf·ft)	
Spark plug	12 N·m (1.2 kgf·m, 9 lbf·ft)	
Valve adjuster hole cap	12 N·m (1.2 kgf·m, 9 lbf·ft)	Apply engine oil to the threads
Valve adjuster lock nut	9 N·m (0.9 kgf·m, 6.5 lbf·ft)	
Oil drain bolt	25 N·m (2.5 kgf·m, 18 lbf·ft)	
Clutch adjuster lock nut	12 N·m (1.2 kgf·m, 9 lbf·ft)	
Rear axle nut	47 N·m (4.8 kgf·m, 35 lbf·ft)	U-nut

## TOOLS

Valve adjusting wrench, 8 × 9 mm	07708-0030100	Equivalent commercially available in U.S.A.
Valve adjuster B	07708-0030400	or 07908-KE90200 (U.S.A. only)
Spoke wrench, 4.1 × 4.5 mm	07701-0020100	Equivalent commercially available in U.S.A.

# MAINTENANCE SCHEDULE

Perform the PRE-RIDE INSPECTION in the Owner's Manual at each scheduled maintenance period.

I: Inspect and Clean, Adjust, Lubricate or Replace if necessary.

C: Clean R: Replace A: Adjust L: Lubricate

ITEMS	FREQUENCY	WHICHEVER COMES FIRST →	REGULAR MAINTENANCE INTERVAL					Refer to page	
			INITIAL MAINTENANCE	600	1,200	1,800	2,400		
			mi	100	600	1,200	1,800		2,400
		→	mi	km	mi	km	mi	km	
		NOTE	MONTH	1	6	12	18	24	
EMISSION RELATED ITEMS	* FUEL LINE					I		I	3-4
	* THROTTLE OPERATION					I		I	3-4
	AIR CLEANER	NOTE 1			C	C	C	C	3-5
	SPARK PLUG				I	I	I	I	3-6
	* VALVE CLEARANCE			I	I	I	I	I	3-7
	ENGINE OIL			R	R	R	R	R	3-8
	** ENGINE OIL STRAINER SCREEN					C		C	3-10
	** ENGINE OIL CENTRIFUGAL FILTER					C		C	3-10
	** ENGINE IDLE SPEED			I	I	I	I	I	3-11
	DRIVE CHAIN	NOTE 1		I, L	I, L: Every 300 mi (500 km) or 3 months				3-12
NON-EMISSION RELATED ITEMS	DRIVE CHAIN SLIDER				I	I	I	I	3-14
	BRAKE SHOES WEAR				I	I	I	I	3-14
	BRAKE SYSTEM			I	I	I	I	I	3-14
	CLUTCH SYSTEM			I	I	I	I	I	3-16
	SIDE STAND					I		I	3-16
	* SUSPENSION					I		I	3-16
	* SPARK ARRESTER				C: Every 1,000 mi (1,600 km) or Every 100 operating hours				3-17
	* NUTS, BOLTS, FASTENERS			I		I		I	3-18
	** WHEELS/TIRES			I	I	I	I	I	3-18
	** STEERING HEAD BEARINGS			I	I	I	I	I	3-19

\* Should be serviced by your Honda dealer, unless the owner has proper tools and service data and is mechanically qualified.

\*\* In the interest of safety, we recommend these items be serviced only by your Honda dealer.

NOTE: 1. Service more frequently when ridden in wet or dusty conditions.

## MAINTENANCE

### FUEL LINE

Check the fuel line for deterioration, damage or leakage. Replace the fuel line if necessary.



### FUEL STRAINER SCREEN

#### ▲WARNING

- *Gasoline is extremely flammable and is explosive under certain conditions. Work in a well ventilated area. Smoking or allowing flames or sparks in the work area or where the gasoline is stored can cause a fire or explosion.*
- *Wipe spilled gasoline at once.*

Turn the fuel valve OFF and disconnect the fuel tube.

Place a drain pan under the fuel tube and turn the fuel valve ON to drain the fuel tank.

After the tank has drained completely, remove the two bolts and collars, and remove the fuel valve and strainer screen.



Wash the fuel strainer screen in non-flammable or high flash solvent.

Check the O-ring is in good condition, reinstall the fuel valve.

Tighten the fuel valve mounting bolts to the specified torque.

**TORQUE:** 9 N·m (0.9 kgf·m , 6.5 lbf·ft)

After installation, check for fuel leaks.



### THROTTLE OPERATION


Check for smooth throttle grip full opening and automatic full closing in all steering positions.

Check the throttle cable and replace it if it is deteriorated, kinked or damaged.

Lubricate the throttle cable, if throttle operation is not smooth.

Measure the free play at the throttle grip flange.


**FREE PLAY:** 2.0 – 4.0 mm (1/16 – 3/16 in)



Throttle grip free play can be adjusted at the upper end of the throttle cable.


Remove the dust cover from the adjuster.  
Adjust the free play by loosening the lock nut and turning the adjuster.  
Tighten the lock nut and install the dust cover properly.

Recheck the throttle operation.




## AIR CLEANER

Remove the two screws and the air cleaner housing cover.




Remove the air cleaner element holder and element from the housing.



Wash the element in non-flammable or high flash point solvent, and let it dry thoroughly.

Soak the element in Pro Honda Foam Filter Oil or equivalent, and squeeze out any excess oil.




## MAINTENANCE

Reinstall the air cleaner element and the element holder by aligning the cutout with the projection on the housing.

Apply grease into the mating groove in the air cleaner housing cover.

Install the housing cover and tighten the screws.

*Align the groove in the cover with the projection on the housing.*



## SPARK PLUG


### REMOVAL

*Clean around the spark plug base with compressed air before removing, and be sure that no debris is allowed to enter the combustion chamber.*

Disconnect the spark plug cap.

Remove the spark plug using a spark plug wrench or an equivalent.


Inspect or replace as described in the maintenance schedule (page 3-3).



### INSPECTION

Check the following and replace if necessary (recommended spark plug: page 3-1)

- Insulator for damage
- Electrodes for wear
- Burning condition, coloration;
  - dark to light brown indicates good condition.
  - excessive lightness indicates malfunctioning ignition system or lean mixture.
  - wet or black sooty deposit indicates over-rich mixture.



### REUSING A SPARK PLUG


Clean the spark plug electrodes with a wire brush or special plug cleaner.

Check the gap between the center and side electrodes with a wire-type feeler gauge.

If necessary, adjust the gap by bending the side electrode carefully.

#### SPARK PLUG GAP:

0.60–0.70 mm (0.024–0.028 in)



**CAUTION:**

*To prevent damage to the cylinder head, hand-tighten the spark plug before using a wrench to tighten to the specified torque.*

Reinstall the spark plug in the cylinder head and hand tighten, then torque it using a spark plug wrench.

**TORQUE:** 12 N·m (1.2 kgf·m , 9 lbf·ft)

**REPLACING A SPARK PLUG**



Set the plug gap to specification with a wire-type feeler gauge (see previous page).

**CAUTION:**

*Do not overtighten the spark plug.*

Install and hand tighten the new spark plug, then tighten it about 1/2 of a turn after the sealing washer contacts the seat of the plug hole.

Install the spark plug cap.




**VALVE CLEARANCE**

**INSPECTION**

*Inspect and adjust the valve clearance while the engine is cold (below 95°F/35°C).*

Remove the valve adjuster hole caps.




Remove the left crankcase cover (page 10-2).

Turn the crankshaft counterclockwise and align the "T" mark on the flywheel with the index notch on the left crankcase.

Make sure the piston at TDC (Top Dead Center) on the compression stroke.

This position can be obtained by confirming that there is slack in the rocker arm.

If there is no slack, rotate the crankshaft one full turn counterclockwise and match up the "T" mark again.




## MAINTENANCE

Check the valve clearance by inserting a feeler gauge between the valve adjusting screw and valve stem.

### VALVE CLEARANCE:

IN/EX:  $0.05 \pm 0.02$  mm ( $0.002 \pm 0.001$  in)



## ADJUSTMENT

Adjust by loosening the lock nut and turning the adjusting screw until there is a slight drag on a feeler gauge.

Hold the adjusting screw and tighten the lock nut.


### TOOLS:

Valve adjusting wrench,  $8 \times 9$  mm

07708-0030100  
(Equivalent commercially available in U.S.A.)

Valve adjuster B

07708-0030400 or  
07908-KE90200  
(U.S.A. only)



**TORQUE:** 9 N·m (0.9 kgf·m, 6.5 lbf·ft)

Recheck the valve clearance.

Check the valve adjuster hole cap O-ring is in good condition, replace if necessary.

Coat the O-rings with clean engine oil and install them in the valve adjuster hole caps.

Apply clean engine oil to the threads, install and tighten the valve adjuster hole caps to the specified torque.



**TORQUE:** 12 N·m (1.2 kgf·m, 9 lbf·ft)


Install the left crankcase cover (page 10-8).

## ENGINE OIL

### OIL LEVEL INSPECTION


Support the motorcycle in an upright position on level ground.

Remove the oil filler cap/dipstick and wipe it clean. Check the oil level by inserting the oil filler cap/dipstick into the oil filler hole without screwing it in.



The engine contains a sufficient amount of oil if the oil level is between the upper and lower level marks on the dipstick.

If the level is near or below the lower level mark, add the recommended oil up to the upper level mark.




**RECOMMENDED ENGINE OIL:**

HONDA GN4 4-stroke oil or equivalent motor oil  
 API service classification: SF or SG  
 Viscosity: 10W-30

**NOTE:**

Other viscosities shown in the chart may be used when the average temperature in your riding area is within the indicated range.




Reinstall the filler cap/dipstick.

**ENGINE OIL CHANGE**

**⚠ WARNING**

*When the engine must be running to do some work, make sure the area is well-ventilated. Never run the engine in an enclosed area. The exhaust contains poisonous carbon monoxide gas that may cause loss of consciousness and lead to death. Run the engine in an open area or with an exhaust evacuation system in an enclosed area.*



OIL FILLER CAP/DIPSTICK

*Change the engine oil with the engine warm and the motorcycle on level ground to assure complete draining.*

Warm up the engine.

Stop the engine and remove the oil filler cap/dipstick and drain bolt.  
 Drain the oil completely.

**⚠ WARNING**

*Used engine oil may cause skin cancer if repeatedly left in contact with the skin for prolonged periods. Although this is unlikely unless you handle used oil on a daily basis, it is still advisable to thoroughly wash your hands with soap and water as soon as possible after handling used oil. KEEP OUT OF REACH OF CHILDREN.*




DRAIN BOLT AND WASHER

## MAINTENANCE

Check that the sealing washer on the drain bolt is in good condition, replace if necessary. Install and tighten the drain bolt.

**TORQUE:** 25 N·m (2.5 kgf·m, 18 lbf·ft)




Fill the crankcase with recommended engine oil (page 3-8).

### OIL CAPACITY:

0.6 l (0.6 US qt, 0.5 Imp qt) at draining  
0.8 l (0.8 US qt, 0.7 Imp qt) at disassembly

Install the oil filler cap/dipstick.

Start the engine and let it idle for 2 to 3 minutes. Stop the engine and recheck the oil level. Make sure there are no oil leaks.




## ENGINE OIL STRAINER SCREEN

### CLEANING

Remove the right crankcase cover (page 9-3).

Remove the oil strainer screen and clean it. Check the screen for damage and the sealing rubber for damage or deterioration.

Reinstall the oil strainer screen and right crankcase cover (page 9-17).




## ENGINE OIL CENTRIFUGAL FILTER

### CLEANING

Remove the right crankcase cover, ball retainer and clutch lifter lever (page 9-3).


Remove the four screws and clutch outer cover.



Clean the clutch outer cover and inside of the clutch outer using a clean lint-free cloth.

**CAUTION:**

- Do not allow dust and dirt to enter the crankshaft oil passage.
- Do not use compressed air.



Reinstall the clutch outer cover using a new gasket (page 9-13).



## ENGINE IDLE SPEED

**▲WARNING**


*When the engine must be running to do some work, make sure the area is well-ventilated. Never run the engine in an enclosed area. The exhaust contains poisonous carbon monoxide gas that may cause loss of consciousness and lead to death. Run the engine in an open area or with an exhaust evacuation system in an enclosed area.*

**NOTE:**

- Inspect and adjust the idle speed after all other engine maintenance items have been performed and are within specifications.
- The engine must be warm for accurate idle speed inspection and adjustment.

Warm up the engine for about ten minutes.  
 Connect a tachometer.  
 Turn the throttle stop screw as required to obtain the specified idle speed.

**IDLE SPEED:** 1,700 ± 100 rpm



## DRIVE CHAIN

### DRIVE CHAIN SLACK INSPECTION

**▲WARNING**

*Never inspect and adjust the drive chain while the engine is running.*

Turn off the engine, place the motorcycle on its side stand and shift the transmission into neutral. Check the slack in the drive chain lower run mid-way between the sprockets.

**CHAIN SLACK:** 15–25 mm (5/8–1 in)

**CAUTION:**

*Excessive chain slack, 40 mm (1-1/2 in) or more, may damage the frame.*

### ADJUSTMENT

Loosen the rear axle nut.  
Loosen the adjuster lock nuts and turn both adjusting nuts an equal number of turn until the correct drive chain slack is obtained.

Make sure the index marks on both adjusters are aligned with the index lines on the swingarm. Tighten the rear axle nut to the specified torque.

**TORQUE:** 47 N·m (4.8 kgf·m , 35 lbf·ft)

Tighten both lock nuts.

Recheck the drive chain slack and free wheel rotation.

Check the rear brake pedal free play (page 3-15), adjust if necessary.





Lubricate the drive chain with #80–90 gear oil. Wipe off the excess oil.

### CLEANING INSPECTION AND LUBRICATION


If the drive chain becomes extremely dirty, it should be removed and cleaned prior to lubrication.

Remove the left crankcase cover (page 10-2).

Carefully remove the retaining clip with pliers. Remove the link plate, master link and drive chain.




Clean the chain with non-flammable or high flash point solvent and wipe it dry.  
 Be sure the chain has dried completely before lubricating.  
 Lubricate the drive chain with # 80 – 90 gear oil.  
 Wipe off the excess gear oil.



Inspect the drive chain for possible damage or wear.  
 Replace any chain that has damaged rollers, loose fitting links, or otherwise appears unserviceable.


Measure the drive chain length between a span of 41 pins (40 links) from pin center to pin center with the chain held taut and any kinked joint straightened.

**SERVICE LIMIT:** 511 mm (20.1 in)




Installing a new chain on badly worn sprockets will cause the new chain to wear quickly.  
 Inspect the drive and driven sprocket teeth for wear or damage. Replace if necessary.  
 Never use a new drive chain on worn sprockets.  
 Both chain and sprockets must be in good condition, or the new replacement parts will wear rapidly.

Check the attaching bolts and nuts on the drive and driven sprockets.  
 If any are loose, torque them.



Install the drive chain onto the sprockets.  
 Install the master link and link plate.  
 Install the retaining clip so that its open end is opposite the normal rotation of the chain.




## MAINTENANCE

### DRIVE CHAIN SLIDER

Check the drive chain slider for wear or damage.



Replace the drive chain slider if the wear limit guide lug is worn out or it has been damaged.



### BRAKE SHOE WEAR

Check the brake shoes and brake drum if the arrow on the indicator plate aligns with the "△" mark on the brake panel when the brake lever is applied.

Refer to page 12-10 or 13-8 for brake shoe and brake drum inspection.




### BRAKE SYSTEM

#### FRONT BRAKE


Measure the front brake lever free play at the tip of the lever.

**FREE PLAY:** 10–20 mm (3/8–13/16 in)



*Make sure the cutout on the adjusting nut is seated on the joint pin.*


Adjust the brake lever free play by turning the adjusting nut.



**REAR BRAKE**


Check the brake pedal free play.

**FREE PLAY:** 10–20 mm (3/8–13/16 in)



*Make sure the cutout on the adjusting nut is seated on the joint pin.*

Adjust the brake pedal free play by turning the adjusting nut.




## MAINTENANCE

### CLUTCH SYSTEM

If the clutch does not operate properly, adjust the following:

Loosen the clutch adjuster lock nut and turn the adjusting bolt one full turn counterclockwise.




Slowly turn the adjusting bolt clockwise until resistance is felt.

Turn the adjusting bolt 1/8 turn counterclockwise from this position, and tighten the lock nut while holding the adjusting bolt.

**TORQUE:** 12 N·m (1.2 kgf·m, 9 lbf·ft)

Check that the clutch is not slipping and is properly disengaging by operating gearshift pedal.




### SIDE STAND

Support the motorcycle on a level surface.

Check the side stand spring for damage or loss of tension.

Check the side stand assembly for freedom of movement and lubricate the side stand pivot if necessary.



### SUSPENSION

#### ⚠WARNING

*Loose, worn or damaged suspension parts impair motorcycle stability and control. Repair or replace any damaged components before riding. Riding a motorcycle with faulty suspension increases your risk of an accident and possible injury.*

#### FRONT SUSPENSION INSPECTION

Check the action of the fork legs by operating the front brake and compressing the front suspension several times.

Check the entire assembly for signs of leaks, damage or loose fasteners.

Replace damaged components which cannot be repaired.

Tighten all nuts and bolts.


Refer to section 12 for fork service.




## REAR SUSPENSION INSPECTION

Support the motorcycle on safety stand or box and raise the rear wheel off the ground.

Hold the swingarm and move the rear wheel sideways with force to see if the wheel bearings are worn.



Check for worn or loose suspension pivot components by grabbing the swingarm and attempting to move the swingarm side to side. Check each fastener of the swingarm and shock absorber, if any are looseness is noted. Also, check the pivot bushings for wear or damage.



Check the action of the shock absorber by compressing it several times. Check the entire shock absorber assembly for signs of leaks, damage or loose fasteners. Replace damaged components which cannot be repaired. Tighten all nuts and bolts.

Refer to section 13 for shock absorber and swingarm service.




## SPARK ARRESTER

### ▲ WARNING


- *Wait until the exhaust system has cooled before removing or installing the spark arrester.*
- *Perform this operation in a well-ventilated area free from combustible materials.*

Remove the three bolts, spark arrester and gasket from the muffler.



## MAINTENANCE


Use a soft brush to remove carbon deposits from the screen mesh, being careful not to damage it. The spark arrester must be free of breaks and holes. Replace if necessary.



Install the spark arrester with a new gasket into the muffler. Tighten the three bolts securely.

## NUTS, BOLTS, FASTENERS

Check that all chassis nuts and bolts are tightened to their correct torque values (page 1-10). Check that all safety clips, clamps and cable stays are in place and properly secured.



## WHEELS/TIRES

*Tire pressure should be checked when the tires are COLD.*


### RECOMMENDED TIRE PRESSURE AND TIRE SIZE:

	FRONT	REAR
Tire pressure kPa (kgf/cm <sup>2</sup> , psi)	100 (1.0 , 15)	125 (1.25 , 18)
Tire size	2.50-10 33J	2.50-10 33J
Tire brand (CHENG SHIN)	C-183A	C-183A

Check the tires for cuts, embedded nails, or other damage. Check the front and rear wheels for trueness (refer to section 12 and 13). Measure the tread depth at the center of the tires. Replace the tires when the tread depth reaches the following limits.

### MINIMUM TREAD DEPTH:


**FRONT/REAR: 3.0 mm (0.12 in)**



Tighten any loose spokes.

**TOOL:**

Spoke wrench, 4.1 × 4.5 mm 07701-0020100  
(Equivalent commercially available  
in U.S.A.)



## STEERING HEAD BEARINGS

*Check that the control cables do not interfere with handlebar rotation.*

Support the motorcycle securely and raise the front wheel off the ground.


Check that the handlebar moves freely from side to side.

If the handlebar moves unevenly, binds, or has vertical movement, inspect the steering head bearings (page 12-15).



# LUBRICATION SYSTEM

## LUBRICATION SYSTEM DIAGRAM



# 4. LUBRICATION SYSTEM

LUBRICATION SYSTEM DIAGRAM	4-0	TROUBLESHOOTING	4-1
SERVICE INFORMATION	4-1	OIL PUMP	4-2

## SERVICE INFORMATION

### GENERAL

4

#### ▲WARNING

- When the engine must be running to do some work, make sure the area is well-ventilated. Never run the engine in an enclosed area. The exhaust contains poisonous carbon monoxide gas that may cause loss of consciousness and lead to death. Run the engine in an open area or with an exhaust evacuation system in an enclosed area.
- Used engine oil may cause skin cancer if repeatedly left in contact with the skin for prolonged periods. Although this is unlikely unless you handle used oil on a daily basis, it is still advisable to thoroughly wash your hands with soap and water as soon as possible after handling used oil. **KEEP OUT OF REACH OF CHILDREN.**

- The oil pump can be serviced with the engine installed in the frame.
- The service procedures in this section must be performed with the engine oil drained.
- When removing and installing the oil pump, use care not to allow dust or dirt to enter the engine.
- If any portion of the oil pump is worn beyond the specified service limits, replace the oil pump as an assembly.
- After the oil pump has been installed, check that there are no oil leaks.

### SPECIFICATIONS

Unit: mm (in)

ITEM		STANDARD	SERVICE LIMIT
Engine oil capacity	At draining	0.6 l (0.6 US qt, 0.5 Imp qt)	————
	At disassembly	0.8 l (0.8 US qt, 0.7 Imp qt)	————
Recommended engine oil		HONDA GN4 4-stroke oil or equivalent motor oil API service classification SF or SG Viscosity: SAE 10W-30	————
Oil pump rotor	Tip clearance	0.15 (0.006)	0.20 (0.008)
	Body clearance	0.02–0.07 (0.001–0.003)	0.12 (0.005)
	Side clearance	0.10–0.15 (0.004–0.006)	0.20 (0.008)

### TORQUE VALUES

Oil pump mounting screw	8 N·m (0.8 kgf·m, 5.8 lbf·ft)
Oil pump cover screw	5 N·m (0.5 kgf·m, 3.6 lbf·ft)

### TROUBLESHOOTING

#### Engine oil level too low – high oil consumption

- Normal oil consumption
- External oil leak
- Worn piston ring or incorrect piston ring installation
- Worn cylinder
- Worn valve guide or stem seal
- Oil pump worn or damaged

#### Oil contamination


- Oil not change often enough
- Worn piston ring or incorrect piston ring installation
- Worn valve guide or stem seal
- Clogged oil strainer screen

# OIL PUMP

## REMOVAL

Remove the clutch assembly (page 9-4).


When the oil pump is ready to be disassembled, loosen the pump cover screws. Remove the three screws and oil pump assembly.



## DISASSEMBLY

Remove the three screws and oil pump cover.

Remove the oil pump shaft, then remove the inner and outer rotors from the oil pump body.




## INSPECTION

*If any portion of the oil pump is worn beyond the specified service limit, replace the oil pump as an assembly.*

Temporarily install the outer and inner rotors into the oil pump body. Install the oil pump shaft.


Measure the tip clearance between the inner and outer rotors.

**SERVICE LIMIT:** 0.20 mm (0.008 in)




Measure the pump body clearance between the outer rotor and pump body.

**SERVICE LIMIT:** 0.12 mm (0.005 in)




Measure the side clearance using a straight edge and feeler gauge.

SERVICE LIMIT: 0.20 mm (0.008 in)




ASSEMBLY



Install the inner and outer rotors into the oil pump body.  
Install the oil pump shaft aligning the flat surfaces of the shaft and inner rotor.


Fill the oil pump with 0.5–1 cm<sup>3</sup> of engine oil.



## LUBRICATION SYSTEM

Install the oil pump cover and tighten the screws to the specified torque.


**TORQUE:** 5 N·m (0.5 kgf·m , 3.6 lbf·ft)



### INSTALLATION

Install the rotor shaft collar into the crankcase.  
Install a new gasket onto the oil pump body.


Install the oil pump into the crankcase while aligning the pump shaft groove with the cam chain guide spindle lug.



Install and tighten the three screws to the specified torque.


**TORQUE:** 8 N·m (0.8 kgf·m , 5.8 lbf·ft)

Install the clutch assembly (page 9-12).



---

**MEMO**



1 N·m (0.1 kgf·m , 0.7 lbf·ft)

# 5. FUEL SYSTEM

5

SERVICE INFORMATION	5-1	CARBURETOR ASSEMBLY	5-6
TROUBLESHOOTING	5-2	CARBURETOR INSTALLATION	5-8
AIR CLEANER HOUSING	5-3	AIR SCREW ADJUSTMENT	5-10
CARBURETOR REMOVAL	5-3	CRANKCASE BREATHER	5-11
CARBURETOR DISASSEMBLY	5-5		

## SERVICE INFORMATION

### GENERAL

#### ▲WARNING

- Gasoline is extremely flammable and is explosive under certain conditions. KEEP OUT OF REACH OF CHILDREN.
- Bending or twisting the control cable will impair smooth operation and could cause the cable to stick or bind, resulting in loss of vehicle control.

- Work in a well ventilated area. Smoking or allowing flames or sparks in the work area or where gasoline is stored can cause a fire or explosion.
- Refer to section 2 for fuel tank removal and installation.
- When disassembling fuel system parts, note the location of the O-rings. Replace them with new ones on reassembly.
- Before disassembling the carburetor, place the suitable container under the carburetor drain tube. Loosen the screw and drain the carburetor.
- After removing the carburetor, wrap the intake port of the engine with a shop towel or cover it with piece of tape to prevent any foreign material from dropping into the engine.

#### NOTE:

If the vehicle is to be stored for more than one month, drain the float bowl. Fuel left in the float bowl may cause clogged jets, resulting in hard starting or poor driveability.

### SPECIFICATIONS

ITEM	SPECIFICATIONS
Carburetor identification number	PA42A
Main jet	# 58
Slow jet	# 35 × # 35
Jet needle clip position	2nd groove from top
Air screw initial opening	1-1/2 turns out
Float level	12.7 mm (0.50 in)
Idle speed	1,700 ± 100 rpm
Throttle grip free play	2.0 – 4.0 mm (1/16 – 3/16 in)

### TORQUE VALUE

Connecting tube band screw 1 N·m (0.1 kgf·m , 0.7 lbf·ft)

### TOOL

Carburetor float level gauge 07401 – 0010000

## FUEL SYSTEM

---

### TROUBLESHOOTING

#### Engine won't to start

- Too much fuel getting to the engine
  - Air cleaner clogged
  - Flooded carburetor
- Intake air leak
- Fuel contaminated/deteriorated
- No fuel to carburetor
  - Fuel strainer clogged
  - Fuel tube clogged
  - Float level misadjusted
  - Fuel tank breather tube clogged

#### Lean mixture

- Fuel jets clogged
- Float valve faulty
- Float level too low
- Fuel line restricted
- Carburetor air vent tube clogged
- Intake air leak
- Throttle valve faulty

#### Rich mixture

- Choke lever in CLOSE position
- Float valve faulty
- Float level too high
- Air jets clogged
- Air cleaner element contaminated
- Flooded carburetor

#### Engine stall, hard to start, rough idling

- Fuel line restricted
- Ignition malfunction
- Fuel mixture too lean/rich
- Fuel contaminated/deteriorated
- Intake air leak
- Idle speed misadjusted
- Float level misadjusted
- Fuel tank breather tube clogged
- Air screw misadjusted
- Slow circuit clogged

#### Afterburn when engine braking is used

- Lean mixture in slow circuit

#### Backfiring or misfiring during acceleration

- Ignition system malfunction
- Fuel mixture too lean

#### Poor performance (driveability) and poor fuel economy

- Fuel system clogged
- Ignition system malfunction

## AIR CLEANER HOUSING

### REMOVAL/INSTALLATION


**NOTE:**

Refer to page 3-5 for air cleaner element service.

Disconnect the crankcase breather tubes. Loosen the connecting tube band screw. Remove the bolt and the air cleaner housing assembly.

*At installation, secure the ground eyelet with the air cleaner housing mounting bolt.*

Installation is in the reverse order of removal.



## CARBURETOR REMOVAL


**▲WARNING**

*Gasoline is extremely flammable and is explosive under certain conditions. KEEP OUT OF REACH OF CHILDREN.*

### THROTTLE VALVE


Loosen the carburetor top.

Remove the carburetor top and throttle valve from the carburetor.




## FUEL SYSTEM

Remove the throttle cable from the throttle valve while compressing the throttle valve spring.



Remove the jet needle retainer and jet needle.

Check the throttle valve and jet needle for scratches, wear or damage.



## CARBURETOR BODY


### ▲WARNING

*Gasoline is extremely flammable and is explosive under certain conditions. Work in a well ventilated area. Smoking or allowing flames or sparks in the work area or where the gasoline is stored can cause a fire or explosion.*

Loosen the drain screw and drain the fuel from the float chamber into an approved gasoline container.


Disconnect the fuel tube, air vent tube and drain tube from the carburetor body.

Loosen the carburetor connecting tube band screw. Remove the carburetor mounting bolts, carburetor and insulator.




## CARBURETOR DISASSEMBLY

Remove the screws and float chamber.



Remove the float pin, float and float valve.

Inspect the float for deformation or damage.



Inspect the float valve seat for scores, scratches, clogging and damage.

Check the tip of the float valve where it contacts the valve seat for stepped wear or contamination.

Replace the valve if the tip is worn or contaminated.


Check the operation of the float valve.

Remove the following:

- Main jet
- Needle jet
- Throttle stop screw and spring

Turn the air screw in and carefully count the number of turns until it seats lightly. Make a note of this to use as a reference when reinstalling the air screw.

Remove the air screw and spring.




### CAUTION:


***Damage to the air screw seat will occur if the air screw is tightened against the seat.***

Inspect each jet for wear or damage and replace if necessary.

Clean the jets with cleaning solvent and blow open with compressed air.



# CARBURETOR ASSEMBLY



Blow open each air and fuel passage in the carburetor body with compressed air.




Install the following:

- Throttle stop screw and spring
- Needle jet
- Main jet


**CAUTION:**

*Handle all jets with care. They can easily be scored or scratched.*

Install the air screw with the spring and return it to its original position as noted during removal. Perform the air screw adjustment procedure if a new air screw is installed (page 5-10).



Hang the float valve onto the float arm lip. Install the float and float valve in the carburetor body, then install the float pin through the body and float.



**FLOAT LEVEL INSPECTION**

**NOTE:**

Set the float level gauge so that it is perpendicular to the float chamber face and in line with the main jet.

With the float valve seated and the float arm just touching the valve, measure the float level with the special tool as shown.

**FLOAT LEVEL:** 12.7 mm (0.50 in)




**TOOL:**

**Carburetor float level gauge** 07401-0010000

The float cannot be adjusted. Replace the float assembly if the float level is out of specification.

Install a new O-ring into the carburetor groove properly. Install the float chamber.


Install and tighten the float chamber screws.



## CARBURETOR INSTALLATION

### CARBURETOR BODY

Install new O-rings into the insulator and carburetor body grooves.




Install the carburetor body into the air cleaner connecting tube and the insulator between the manifold and carburetor, then install the mounting bolts.


Tighten the connecting tube band screw and mounting bolts.

### TORQUE:

**Connecting tube:** 1 N·m (0.1 kgf·m , 0.7 lbf·ft)




Connect the fuel tube, drain tube and air vent tube.




### THROTTLE VALVE

Install the needle clip on the jet needle.


**STANDARD POSITION:** 2nd groove from top




Install the jet needle into the throttle valve and secure it with the needle clip retainer.




Check the seal ring is in good condition, replace if necessary.  
Install the throttle valve spring onto the throttle cable.



Connect the throttle cable to the throttle valve while compressing the throttle valve spring.



Install the throttle valve into the carburetor body, aligning its cut-out with the throttle stop screw.



## FUEL SYSTEM

Tighten the carburetor top securely.

After installing the carburetor, check for the following:

- Engine idle speed (page 3-11)
- Throttle grip free play (page 3-4)

## AIR SCREW ADJUSTMENT

### IDLE DROP PROCEDURE

#### ▲WARNING

*When the engine must be running to do some work, make sure the area is well-ventilated. Never run the engine in an enclosed area. The exhaust contains poisonous carbon monoxide gas that may cause loss of consciousness and lead to death. Run the engine in an open area or with an exhaust evacuation system in an enclosed area.*

#### NOTE:

- The air screw is factory pre-set. Adjustment is not necessary unless the carburetor is overhauled or new air screw is installed.
- The engine must be warm for accurate adjustment. Ten minutes of stop-and-go riding is sufficient.
- Use a tachometer with graduations of 50 rpm or smaller that will accurately indicate 50 rpm change.

1. Turn the air screw clockwise until it seats lightly, and then back it out to the specification given.

#### CAUTION:

*Damage to the air screw seat will occur if the air screw is tightened against the seat.*

**INITIAL OPENING:** 1-1/2 turns out



2. Warm the engine up to operating temperature.
3. Stop the engine and connect a tachometer according to the tachometer manufacturer's instructions.
4. Start the engine and adjust the idle speed with the throttle stop screw.

**IDLE SPEED:** 1,700 ± 100 rpm

5. Turn the air screw in or out slowly to obtain the highest engine speed.
6. Lightly open the throttle 2-3 times, then adjust the idle speed with the throttle stop screw.
7. Turn the air screw out gradually until the engine speed drops by 50 rpm.
8. Turn the air screw in to the final opening from the position obtain in step 7.

**FINAL OPENING:** 1/2 turns in

9. Readjust the idle speed with the throttle stop screw.




## CRANKCASE BREATHER

Remove the crankcase breather tube plug and empty any deposits if the deposit level can be seen in the breather tube.


Install the crankcase breather tube plug and secure it with the clip securely.



# ENGINE REMOVAL/INSTALLATION



31 N·m (3.2 kgf·m , 23 lbf·ft)



# 6. ENGINE REMOVAL/INSTALLATION

SERVICE INFORMATION	6-1	ENGINE INSTALLATION	6-4
ENGINE REMOVAL	6-2		

## SERVICE INFORMATION

### GENERAL

- During engine removal and installation, support the motorcycle securely using a hoist or equivalent.
- Support the engine using a jack or other adjustable support to ease of engine hanger bolts removal.
- The following components can be serviced with the engine installed in the frame.
  - Alternator/cam chain tensioner (Section 10)
  - Clutch (Section 9)
  - Cylinder/piston (Section 8)
  - Cylinder head/valves (Section 7)
  - Gearshift linkage (Section 9)
  - Oil pump (Section 4)
- The crankshaft, transmission and kickstarter require engine removal for service (Section 11).

6

### SPECIFICATIONS

ITEM	SPECIFICATIONS
Engine dry weight	17.2 kg (37.9 lbs)
Engine oil capacity at disassembly	0.8 l (0.8 US qt , 0.7 Imp qt)

### TORQUE VALUES

Drive sprocket fixing plate bolt	12 N·m (1.2 kgf·m , 9 lbf·ft)
Engine hanger nut (Upper)	31 N·m (3.2 kgf·m , 23 lbf·ft)
(Lower)	31 N·m (3.2 kgf·m , 23 lbf·ft)

## ENGINE REMOVAL/INSTALLATION

### ENGINE REMOVAL


Drain the engine oil (page 3-9).

Remove the following:

- exhaust system (page 2-5)
- left crankcase cover (page 10-2)

Disconnect the following:

- spark plug cap




- ignition pulse generator and exciter coil connectors



- crankcase breather tube

Remove the following from the clamp:


- carburetor drain tube
- crankcase breather tube




Loosen the rear axle nut and drive chain adjusters to loosen the drive chain (page 3-12)

Remove the following:

- fixing plate bolts
- fixing plate
- drive sprocket



- intake manifold bolts
- O-ring




- brake pedal return spring



*Support the motorcycle securely.*

- four bolts and footpeg bar



## ENGINE REMOVAL/INSTALLATION

---

— engine hanger nuts and washers


Place the floor jack or other adjustable support under the engine.

Remove the hanger bolts and the engine from the frame.

### CAUTION:

*During engine assembly removal, hold the engine securely and be careful not to damage the frame and engine.*

---



## ENGINE INSTALLATION

Install the engine onto the frame in the reverse order of removal.

### NOTE:

- Note the installation of the hanger bolts. All bolts are installed from left side.
  - The jack height must be continually adjusted to relieve stress from the hanger bolts.
- 

Tighten the hanger nuts to the specified torque.

**TORQUE:** 31 N·m (3.2 kgf·m , 23 lbf·ft)

Install the removed parts from engine removal procedure (page 6-2 to 6-3) in the reverse order of removal.

### NOTE:

- Replace the intake manifold O-ring with a new one.
  - Note the installation of the brake pedal return spring.
- 

### TORQUE:


**Fixing plate bolt:** 12 N·m (1.2 kgf·m , 9 lbf·ft)

Install the following:

- left crankcase cover (page 10-8)
- exhaust system (page 2-5)

Adjust the drive chain slack (page 3-12).


Fill the recommended engine oil (page 3-9).



---

MEMO

# CYLINDER HEAD/VALVES



# 7. CYLINDER HEAD/VALVES

SERVICE INFORMATION	7-1	CAMSHAFT REMOVAL	7-3
TROUBLESHOOTING	7-2	CYLINDER HEAD	7-4
CYLINDER COMPRESSION	7-3	CAMSHAFT INSTALLATION	7-15

## SERVICE INFORMATION

### GENERAL

- This section covers service of the cylinder head, valves and camshaft.
- The cylinder head, valves and camshaft services can be done with the engine installed in the frame.
- When disassembling, mark and store the disassembled parts to ensure that they are reinstalled in their original locations.
- Clean all disassembled parts with cleaning solvent and dry them by blowing them off with compressed air before inspection.
- Camshaft lubricating oil is fed through oil passages in the cylinder head. Clean the oil passages before assembling cylinder head.
- Be careful not to damage the mating surfaces when removing the cylinder head cover and cylinder head.
- Refer to section 10 for cam chain tensioner service.

7

### SPECIFICATIONS

Unit: mm (in)

ITEM			STANDARD	SERVICE LIMIT
Cylinder compression			981 – 1,177 kPa (10.0 – 12.0 kgf/cm <sup>2</sup> , 142 – 171 psi) at 1,000 rpm	————
Cylinder head warpage			————	0.05 (0.002)
Valve, valve guide	Valve clearance	IN	0.05 ± 0.02 (0.002 ± 0.001)	————
		EX	0.05 ± 0.02 (0.002 ± 0.001)	————
	Valve stem O.D.	IN	4.970 – 4.985 (0.1957 – 0.1963)	4.92 (0.194)
		EX	4.955 – 4.970 (0.1951 – 0.1957)	4.92 (0.194)
	Valve guide I.D.	IN/EX	5.000 – 5.012 (0.1969 – 0.1973)	5.03 (0.198)
	Stem-to-guide clearance	IN	0.015 – 0.042 (0.0006 – 0.0017)	0.08 (0.003)
		EX	0.030 – 0.057 (0.0012 – 0.0022)	0.10 (0.004)
Valve seat width	IN/EX	1.0 – 1.3 (0.04 – 0.05)	2.0 (0.08)	
Valve spring free length			IN/EX 33.34 (1.313)	31.8 (1.25)
Rocker arm/shaft	Rocker arm I.D.	IN/EX	10.000 – 10.015 (0.3937 – 0.3943)	10.10 (0.398)
	Rocker arm shaft O.D.	IN/EX	9.978 – 9.987 (0.3928 – 0.3932)	9.91 (0.390)
Camshaft	Cam lobe height	IN	20.003 – 20.123 (0.7875 – 0.7922)	19.66 (0.774)
		EX	19.994 – 20.114 (0.7872 – 0.7919)	19.65 (0.774)

### TORQUE VALUES

Cylinder head nut	11 N·m (1.1 kgf·m, 8 lbf·ft)
Cylinder head right side cover bolt	10 N·m (1.0 kgf·m, 7 lbf·ft)
Cam sprocket bolt	9 N·m (0.9 kgf·m, 6.5 lbf·ft)

## CYLINDER HEAD/VALVES

---

### TOOLS

Valve spring compressor	07757-0010000	
Valve spring compressor attachment	07959-KM30101	
Valve guide driver, 5.0 mm	07742-MA60000	
Valve guide reamer, 5.0 mm	07984-MA60001	or 07984-MA6000C (U.S.A. only)
Valve seat cutters		- These are commercially available in U.S.A.
Seat cutter, 24 mm (45° IN)	07780-0010600	
Seat cutter, 20.5 mm (45° EX)	07780-0011000	
Flat cutter, 24 mm (32° IN)	07780-0012500	
Flat cutter, 21.5 mm (32° EX)	07780-0012800	
Interior cutter, 22 mm (60° IN/EX)	07780-0014202	
Cutter holder, 5 mm	07781-0010400	

### TROUBLESHOOTING

- Engine top-end problems usually affect engine performance. These problem can be diagnosed by a compression test or by tracing engine noises to the top-end with a sounding rod stethoscope.
- If the performance is poor at low speeds, check for white smoke in the crankcase breather tube. If the tube is smoky check for a seized piston ring (Section 8).

#### Compression too low, hard starting or poor performance at low speed

- Valves:
  - Incorrect valve clearance
  - Burned or bent valve
  - Incorrect valve timing
  - Broken valve spring
  - Uneven valve seating
- Cylinder head:
  - Leaking or damaged head gasket
  - Warped or cracked cylinder head
- Worn cylinder, piston or piston rings (section 8)

#### Compression too high, overheating or knocking

- Excessive carbon build-up on piston crown or on combustion chamber

#### Excessive smoke

- Cylinder head:
  - Worn valve stem or valve guide
  - Damaged stem seal
- Worn cylinder, piston or piston rings (section 8)

#### Excessive noise

- Cylinder head:
  - Incorrect valve clearance
  - Sticking valve or broken valve spring
  - Damaged or worn camshaft
  - Loose or worn cam chain
  - Worn or damaged cam chain
  - Worn or damaged cam chain tensioner (section 10)
  - Worn cam sprocket teeth
  - Worn rocker arm and/or shaft
- Worn cylinder, piston or piston rings (section 8)

#### Rough idle

- Low cylinder compression

## CYLINDER COMPRESSION

Warm up the engine to normal operating temperature.

Stop the engine and remove the spark plug (page 3-6).

Install a compression gauge.

Shift the transmission in neutral and open the choke lever (OFF).

Open the throttle all the way and crank the engine with the kickstarter until the gauge reading stops rising.

### COMPRESSION PRESSURE:

981 – 1,177 kPa (10.0 – 12.0 kgf/cm<sup>2</sup>, 142 – 171 psi) at 1,000 rpm

Low compression can be caused by:

- Blown cylinder head gasket
- Improper valve adjustment
- Valve leakage
- Worn piston ring or cylinder

High compression can be caused by:

- Carbon deposits in combustion chamber or on piston head



## CAMSHAFT REMOVAL

Drain the engine oil (page 3-9).

Remove the following:

- valve adjuster hole cap (page 3-7)
- left crankcase cover (page 10-2)
- sealing bolt, tensioner spring and tensioner push rod to loosen the cam chain tensioner (page 10-4)

Disconnect the spark plug cap.



Loosen the cylinder head side cover 6 mm bolt.

Tap the head of the 6 mm bolt and release the cylinder head left side cover from the cylinder head. Remove the 6 mm bolt, sealing washer and cylinder head left side cover.

Turn the crankshaft counterclockwise, and align the "O" mark on the cam sprocket with the index notch on the cylinder head.


Remove the bolts, cam sprocket and dowel pin.

*Secure the cam chain with a piece of wire to prevent it from falling into the cylinder.*




## CYLINDER HEAD/VALVES

Loosen the valve adjusting screw fully to make a valve clearance maximum (page 3-8).  
Temporarily install the cam sprocket bolts into the camshaft and remove the camshaft from the cylinder head while holding the rocker arms.



### INSPECTION


Turn the outer race of the each camshaft bearing with your finger.  
The outer race should turn smoothly and quietly.  
Also check that the bearing inner race fits tightly on the camshaft.  
Replace the camshaft assembly if the outer race does not turn smoothly and quietly, or if it fits loosely on the camshaft.



Using a micrometer, measure each cam lobe height.

### SERVICE LIMITS:

- IN: 19.66 mm (0.774 in)
- EX: 19.65 mm (0.774 in)




## CYLINDER HEAD

### REMOVAL

Remove the following:  
- Muffler (page 2-4)  
- Camshaft (page 7-3)

Remove the intake manifold bolts.



Remove the following:


- Cap nuts/sealing washers
- Nut/sealing washer
- Cylinder head cover
- Gasket

Remove the cylinder head mounting bolt and cylinder head.



Remove the following:


- Gasket
- Dowel pins
- Collar
- O-ring




### DISASSEMBLY

Remove the spark plug.

Remove the bolts and cylinder head right side cover.



Temporarily install a 8 mm bolt to the rocker arm shaft and remove the rocker arm shafts and rocker arms.



## CYLINDER HEAD/VALVES


Remove the valve spring cotters using the special tools as shown.

### TOOLS:

Valve spring compressor 07757-0010000  
Valve spring compressor attachment 07959-KM30101

### CAUTION:


*To prevent loss of tension, do not compress the valve springs more than necessary to remove the cotters.*



Mark all parts during disassembly so they can be placed back in their original locations.

Remove the following:

- Spring retainer
- Valve spring
- Valve
- Stem seal
- Valve spring seat




## INSPECTION

### CYLINDER HEAD


Remove carbon deposits from the combustion chamber.

Avoid damaging the gasket surface. Check the spark plug hole and valve areas for cracks.



Check the cylinder head for warpage with a straight edge and feeler gauge.

**SERVICE LIMIT:** 0.05 mm (0.002 in)




### ROCKER ARM

*If either rocker arm requires service or replacement, inspect the cam lobes for scoring, chipping or flat spots.*

Inspect the rocker arm slipper surfaces for wear or damage.  
Also check that the oil holes are not clogged.

Measure the rocker arm I.D.


**SERVICE LIMIT: IN/EX: 10.10 mm (0.398 in)**



Inspect the rocker arm shafts for wear or damage.

Measure the O.D. of the rocker arm shaft.

**SERVICE LIMIT: IN/EX: 9.91 mm (0.390 in)**




### VALVE SPRING

Measure the free length of the inner and outer valve springs.

**SERVICE LIMITS: IN/EX: 31.8 mm (1.25 in)**

Replace the springs if they are shorter than the service limits.




### VALVE

Inspect each valve for bending, burning or abnormal stem wear.

Check valve movement in the guide.  
Measure and record each valve stem O.D.

**SERVICE LIMIT: IN/EX: 4.92 mm (0.194 in)**



## CYLINDER HEAD/VALVES

Ream the guides to remove any carbon deposits before measuring the guide. Insert the reamer from the combustion chamber side of the head and always rotate the reamer clockwise.

### TOOL:

**Valve guide reamer, 5.0 mm** 07984—MA60001 or 07984—MA6000C (U.S.A. only)

Measure and record each valve guide I.D.

**SERVICE LIMIT: IN/EX:** 5.03 mm (0.198 in)

Subtract each valve stem O.D. from the corresponding guide I.D. to obtain the stem-to-guide clearance.

### SERVICE LIMITS:



**IN:** 0.08 mm (0.003 in)

**EX:** 0.10 mm (0.004 in)

*Reface the valve seats whenever the valve guides are replaced (page 7-9).*

If the stem-to-guide clearance is out of specification, determine if a new guide with standard dimensions would bring the clearance within tolerance. If so, replace any guides as necessary and ream to fit. If the stem-to-guide clearance is out of specification with a new guide, also replace the valve.

VALVE GUIDE REAMER



## VALVE GUIDE REPLACEMENT

Chill new valve guides in the freezer section of a refrigerator for about an hour. Heat the cylinder head to 212–302°F (100–150°C) with a hot plate or oven.

### ▲WARNING

*To avoid burns, wear heavy gloves when handling the heated cylinder head.*

### CAUTION:


*Do not use a torch to heat the cylinder head; it may cause warping.*

Support the cylinder head and drive out the valve guides out of the cylinder head from the combustion chamber side.

### TOOL:

**Valve guide driver, 5.0 mm** 07942—MA60000


VALVE GUIDE DRIVER



Coat new O-rings with engine oil and install them onto new valve guides.  
While the cylinder is still heated, drive the guides in the cylinder head from the camshaft side until they are fully seated.

**TOOL:**  
Valve guide driver, 5.0 mm 07942-MA60000


Let the cylinder head cool to room temperature.



Ream the new valve guide after installation. Insert the reamer from the combustion chamber side of the head and always rotate the reamer clockwise.

**TOOL:**  
Valve guide reamer, 5.0 mm 07984-MA60001 or 07984-MA6000C (U.S.A. only)


**NOTE:**  
Use cutting oil on the reamer during this operation.



Clean the cylinder head thoroughly to remove any metal particles.  
Reface the valve seat (see below)

## VALVE SEAT INSPECTION/REFACING

Clean the intake and exhaust valves thoroughly to remove carbon deposits.  
Apply a light coating of Prussian Blue to the valve seats. Lap the valves and seats using a rubber hose or other hand-lapping tool.




Remove and inspect the valves.

**CAUTION:**  
*The valves cannot be ground. If a valve face is burned or badly worn or if it contacts the seat unevenly, replace the valve.*

Inspect the width of each valve seat.

**STANDARD:** 1.0-1.3 mm (0.04-0.05 in)  
**SERVICE LIMIT:** 2.0 mm (0.08 in)

If the seat is too wide, too narrow or has low spots, the seat must be ground.




## VALVE SEAT REFACING

Valve seat cutters/grinders or equivalent valve seat refacing equipment are recommended to correct worn valve seats.


**NOTE:**

Follow the refacing manufacturer's operating instructions.


### VALVE SEAT CUTTERS (EQUIVALENT COMMERCIALLY AVAILABLE IN U.S.A.)



IN: 07780-0012500 (24 mm/30°)  
EX: 07780-0012800 (21.5 mm/32°)




IN: 07780-0010600 (24 mm)  
EX: 07780-0011000 (20.5 mm)




IN, EX 07780-0014202 (22 mm)


*Reface the seat with a 45-degree cutter whenever a valve guide is replaced.* Use a 45-degree cutter to remove any roughness or irregularities from the seat.




Use a 32-degree (IN: 30°) cutter to remove the top 1/4 of the existing valve seat material.



Use a 60-degree cutter to remove the bottom 1/4 of the old seat.  
Remove the cutter and inspect the area you have refaced.



Install a 45-degree finish cutter and cut the seat to the proper width.  
Make sure that all pitting and irregularities are removed.  
Refinish if necessary.




Apply a thin coating of Prussian Blue to the valve seat.  
Press the valve through the valve guide and onto the seat to make a clear pattern.

**NOTE:**


The location of the valve seat in relation to the valve face is very important for good sealing.

If the contact area is too high on the valve, the seat must be lowered using a 32-degree flat cutter.



If the contact area is too low on the valve, the seat must be raised using a 60-degree inner cutter.

Refinish the seat to specifications, using a 45-degree finish cutter.




## CYLINDER HEAD/VALVES

After cutting the seat, apply lapping compound to the valve face, and lap the valve using light pressure.


*Do not allow lapping compound to enter the guides.*

After lapping, wash all residual compound off the cylinder head and valve.

HAND-LAPPING TOOL



## ASSEMBLY




Clean the cylinder head assembly with solvent and blow through all oil passages with compressed air.

Install the valve spring seats.  
Install new stem seals.

Lubricate the valve stems with engine oil and insert the valve into the valve guide.  
To avoid damage to the stem seal, turn the valve slowly when inserting.

Install the valve springs with the tightly wound coils facing the combustion chamber.  
Install the valve spring retainer.




Install the valve cotters using the special tool as shown.

**TOOL:**

Valve spring compressor 07757-001000  
 Valve spring compressor attachment  
 07959-KM30101

**CAUTION:**


*To prevent loss of tension, do not compress the valve spring more than necessary.*



Tap the valve stems gently with two plastic hammers as shown to seat the cotters firmly.

**CAUTION:**


*Support the cylinder head above the work bench so that the valve heads will not contact anything that cause damage.*



Apply engine oil to the rocker arm inner and slipper surfaces.


Install the rocker arms and rocker arm shafts.

*Install the rocker arm shaft with its threaded end facing the right side.*




Install a new gasket onto the cylinder head right side cover.

Install the right side cover onto the cylinder head.




## CYLINDER HEAD/VALVES

Install the right side cover bolts.




### INSTALLATION

Clean off the gasket material from the cylinder surface.



Install the following:


- New O-ring
- Collar
- Dowel pins
- New gasket



Route the cam chain through the cylinder head and install the cylinder head.

*Install the cylinder head cover with its arrow mark facing down.*

Install a new gasket onto the cylinder head and then install the cylinder head cover.



Install the following:

- Cap nuts/new sealing washers
- Nut/new sealing washer

**NOTE:**

Note the position of the washers and nuts.

Tighten the cylinder head cover nuts to the specified torque.

**TORQUE:** 11 N·m (1.1 kgf·m , 8 lbf·ft)




Install and tighten the cylinder head mounting bolt. If the cylinder was removed, tighten the cylinder mounting bolt.

Install a new O-ring into the groove in the intake manifold.

Install and tighten the intake manifold bolts.

Install the following:


- Spark plug (page 3-7)
- Muffler (page 2-4)
- Camshaft (see below)



## CAMSHAFT INSTALLATION


Apply clean engine oil to the camshaft lobes and bearings.

Install the camshaft into the cylinder head with its cam lobes facing the combustion chamber while holding the rocker arms.



## CYLINDER HEAD/VALVES

Turn the crankshaft counterclockwise and align the "T" mark with the index notch on the left crankcase.




Install the dowel pin and cam sprocket.

**NOTE:**

Install the cam sprocket with its "O" mark with the index notch on the cylinder head.

Install and tighten the cam sprocket bolts to the specified torque.

**TORQUE:** 9 N·m (0.9 kgf·m , 6.5 lbf·ft)



Install the cylinder head left side cover onto the cylinder head with a new gasket.




Set the tab on the side cover against the left side of the stopper on the cylinder head.

Install the 6 mm bolt with a new sealing washer into the cylinder head and tighten it.

Tighten the two right side cover bolts if the cylinder head was disassembled.

Install the spark plug cap.


**TORQUE:** 10 N·m (1.0 kgf·m , 7 lbf·ft)



Install the tensioner push rod, spring and sealing bolt (page 10-5).


Adjust the valve clearance (page 3-7).

Pour the recommended engine oil (page 3-9).



# CYLINDER/PISTON

---



# 8. CYLINDER/PISTON

SERVICE INFORMATION	8-1	CYLINDER/PISTON INSPECTION	8-4
TROUBLESHOOTING	8-2	PISTON INSTALLATION	8-7
CYLINDER REMOVAL	8-3	CYLINDER INSTALLATION	8-7
PISTON REMOVAL	8-3		

## SERVICE INFORMATION

### GENERAL

- The cylinder and piston service can be done with the engine installed in the frame.
- Camshaft lubrication oil is fed to the cylinder head through an orifice in the cylinder head, cylinder and crankcase. Be sure that this orifice is not clogged and that the O-rings and dowel pins are in place before installing the cylinder.

### SPECIFICATIONS

Unit: mm (in)

8

ITEM		STANDARD	SERVICE LIMIT	
Cylinder	I.D.	39.005 – 39.015 (1.5356 – 1.5360)	39.05 (1.537)	
	Out of round	—	0.10 (0.004)	
	Taper	—	0.10 (0.004)	
	Warpage	—	0.05 (0.002)	
Piston, piston rings	Piston mark direction	"IN" mark facing toward the intake side	—	
	Piston O.D.	38.975 – 38.995 (1.5344 – 1.5352)	38.90 (1.531)	
	Piston O.D. measurement point	8 mm (0.3 in) from bottom of skirt	—	
	Piston pin bore I.D.	13.002 – 13.008 (0.5119 – 0.5121)	13.06 (0.514)	
	Piston pin O.D.	12.994 – 13.000 (0.5116 – 0.5118)	12.98 (0.511)	
	Piston-to-piston pin clearance	0.002 – 0.014 (0.0001 – 0.0006)	0.08 (0.003)	
	Piston ring-to-ring groove clearance	Top/Second	0.015 – 0.050 (0.0006 – 0.0020)	0.12 (0.005)
		Piston ring end gap	Top	0.05 – 0.15 (0.002 – 0.006)
	Second		0.05 – 0.20 (0.002 – 0.008)	0.5 (0.02)
	Oil (side rail)		0.3 – 0.9 (0.01 – 0.04)	1.1 (0.04)
Cylinder-to-piston clearance		0.010 – 0.040 (0.0004 – 0.0016)	0.15 (0.006)	
Connecting rod small end I.D.		13.016 – 13.034 (0.5124 – 0.5131)	13.08 (0.515)	
Connecting rod-to-piston pin clearance		0.016 – 0.040 (0.0006 – 0.0016)	0.12 (0.005)	

### TORQUE VALUES

Cam chain guide roller pin bolt

10 N·m (1.0 kgf·m , 7 lbf·ft)

### TROUBLESHOOTING

- If the performance is poor at low speeds, check for white smoke in the crankcase breather tube. If the tube is smoky, check for a seized piston ring.

#### **Cylinder compression is too low, or engine is hard to start**

- Blown cylinder head gasket
- Worn, stuck or broken piston ring
- Worn or damaged cylinder or piston

#### **Cylinder compression is too high, or engine overheats or knocks**

- Carbon deposits on the cylinder head and/or piston crown

#### **Piston sounds**

- Worn cylinder, piston and/or piston ring
- Worn piston pin hole and piston pin
- Worn connecting rod small end

#### **Excessive smoke**


- Worn, stuck or broken piston ring

## CYLINDER REMOVAL

Remove the cylinder head (page 7-4).


Remove the cam chain guide roller pivot bolt, washer and guide roller.

Remove the mounting bolt and cylinder.



Remove the following:

- Rubber packing
- Gasket
- Dowel pins




## PISTON REMOVAL

*Do not let the piston pin clips fall into the crankcase.*


Remove the piston pin clip with pliers.

Press the piston pin out of the piston and remove the piston.



*Do not damage the piston rings during removal.*

Remove the piston rings.



### CYLINDER/PISTON INSPECTION

Inspect the cylinder bore for wear or damage. Measure the cylinder I.D. in X and Y axis at three levels. Take the maximum reading to determine the cylinder wear.

**SERVICE LIMIT:** 39.05 mm (1.537 in)

Calculate the piston-to-cylinder clearance. Take a maximum reading to determine the clearance. Refer to page 8-5 for measurement of the piston O. D.

**SERVICE LIMIT:** 0.15 mm (0.006 in)

Calculate the taper and out of round at three levels in X and Y axis. Take the maximum reading to determine them.

**SERVICE LIMITS:**

**Taper:** 0.10 mm (0.004 in)

**Out of round:** 0.10 mm (0.004 in)

The cylinder must be rebored and an oversize piston fitted if the service limits are exceeded.

The following oversize pistons are available:

0.25 mm (0.010 in)





0.50 mm (0.020 in)

The piston to cylinder clearance for the oversize piston must be: 0.010 – 0.040 mm (0.0004 – 0.0016 in).

Inspect the top of the cylinder for warpage.

**SERVICE LIMIT:** 0.05 mm (0.002 in)

Remove any carbon deposits from the piston ring grooves, using an old piston ring as shown.




Temporarily install the piston rings to their proper position with the mark facing up.

Measure the piston ring-to-ring groove clearance with the rings pushed into the grooves.

**SERVICE LIMITS:**

**Top:** 0.12 mm (0.005 in)


**Second:** 0.12 mm (0.005 in)



Inspect the piston for wear or damage.


Measure the diameter of the piston at 8 mm (0.3 in) from the bottom and 90 degrees to the piston pin hole.

**SERVICE LIMIT:** 38.90 mm (1.531 in)



Measure the piston pin bore.

**SERVICE LIMIT:** 13.06 mm (0.514 in)




Measure the O.D. of the piston pin.

**SERVICE LIMIT:** 12.98 mm (0.511 in)

Calculate the piston-to-piston pin clearance.

**SERVICE LIMIT:** 0.08 mm (0.003 in)




## CYLINDER/PISTON

Measure the connecting rod small end I.D.

**SERVICE LIMIT:** 13.08 mm (0.515 in)

Calculate the connecting rod-to-piston pin clearance.

**SERVICE LIMIT:** 0.12 mm (0.005 in)



*Push the rings into the cylinder with the top of the piston to be sure they are squarely in the cylinder.*


Insert the piston ring squarely into the bottom of the cylinder and measure the ring end gap.

**SERVICE LIMITS:**

**Top:** 0.5 mm (0.02 in)

**Second:** 0.5 mm (0.02 in)

**Oil (side rail):** 1.1 mm (0.04 in)



## PISTON RING INSTALLATION


Clean the piston ring grooves thoroughly and install the piston rings.

**NOTE:**

- Apply oil to the piston rings.
- Avoid piston and piston ring damage during installation.
- Install the piston rings with their marking facing up.
- Do not confuse the top and second rings.

Space the piston ring end gaps 120 degrees apart. Do not align the gaps in the oil rings (side rails).

After installation, the rings should rotate freely in the ring grooves.




## PISTON INSTALLATION

Apply oil to the piston pin outer surface.  
Install the piston with its "IN" mark facing the intake side.  
Install the piston pin and secure it with new piston pin clips.

### NOTE:

- Do not align the piston pin clips end gap with the piston cut-out.
- Do not let the piston pin clips fall into the crankcase.



## CYLINDER INSTALLATION




Clean off any gasket materials from the crankcase surface.

Install the dowel pins, new gasket and new rubber packing.

Coat the cylinder bore, piston outer surface and piston ring grooves with clean engine oil.  
Route the cam chain through the cylinder and install the cylinder while compressing the piston rings.

### NOTE:

- Avoid piston ring damage during installation.
- Do not let the cam chain fall into the crankcase.




## CYLINDER/PISTON

Apply engine oil to the guide roller inner surface.  
Install the cam chain guide roller, new sealing washer and pin bolt.  
Tighten the cam chain guide roller pin bolt to the specified torque.

**TORQUE:** 10 N·m (1.0 kgf·m, 7 lbf·ft)

Install the cylinder mounting bolt but do not tighten it yet.

Install the cylinder head (page 7-14).




---

MEMO

---

# CLUTCH/GEARSHIFT LINKAGE



# 9. CLUTCH/GEARSHIFT LINKAGE

SERVICE INFORMATION	9-1	CLUTCH	9-4
TROUBLESHOOTING	9-2	GEARSHIFT LINKAGE	9-14
RIGHT CRANKCASE COVER REMOVAL	9-3	RIGHT CRANKCASE COVER INSTALLATION	9-17

## SERVICE INFORMATION

### GENERAL

- This section covers service of the clutch and gearshift linkage. All service can be done with the engine installed in the frame.
- Use care not to allow dust or dirt to enter the engine.
- Transmission oil viscosity and level have an effect on clutch disengagement. When the clutch does not disengage or the motorcycle creeps with clutch disengaged, inspect the transmission oil level before servicing the clutch system.

### SPECIFICATIONS

Unit: mm (in)

ITEM		STANDARD	SERVICE LIMIT
Clutch disc thickness	A	2.52–2.68 (0.099–0.106)	2.3 (0.09)
	B	3.32–3.48 (0.131–0.137)	3.0 (0.12)
Clutch plate warpage		—	0.20 (0.008)
Centrifugal clutch spring free length		22.4 (0.88)	19.4 (0.76)
Primary drive gear I.D.		21.000–21.021 (0.8268–0.8276)	21.05 (0.829)
Clutch center guide	I.D.	16.988–17.006 (0.6688–0.6695)	17.04 (0.671)
	O.D.	20.930–20.950 (0.8240–0.8248)	20.90 (0.823)
Crankshaft O.D. at clutch center guide		16.966–16.984 (0.6680–0.6687)	16.90 (0.665)

9

### TORQUE VALUES

Clutch outer cover screw	5 N·m (0.5 kgf·m , 3.6 lbf·ft)
Clutch lock nut	42 N·m (4.3 kgf·m , 31 lbf·ft)
Clutch assembly screw	6 N·m (0.6 kgf·m , 4.3 lbf·ft)
Shift drum stopper arm bolt	13 N·m (1.3 kgf·m , 9 lbf·ft)
Shift return spring pin bolt	29 N·m (3.0 kgf·m , 22 lbf·ft)
Gearshift cam plate bolt	17 N·m (1.7 kgf·m , 12 lbf·ft)

### TOOLS

Flywheel holder	07725–0040000	Equivalent commercially available in U.S.A.
Lock nut wrench, 20 × 24 mm	07716–0020100	
Extension bar	07716–0020500	Equivalent commercially available in U.S.A.

### TROUBLESHOOTING

#### Clutch slips when accelerating

- Incorrect clutch adjustment
- Worn clutch disc
- Weak clutch springs
- Faulty clutch weight
- Transmission oil mixed with molybdenum or graphite additive

#### Motorcycle creeps with clutch disengaged

- Incorrect clutch adjustment
- Clutch plate warped
- Faulty clutch lifter
- Faulty clutch weight
- Incorrect engine oil weight

#### Hard to shift

- Incorrect clutch adjustment
- Loose stopper plate bolt
- Damaged stopper plate and pin
- Damaged gearshift spindle

#### Transmission jumps out of gear

- Worn shift drum stopper arm
- Weak or broken shift arm return spring
- Loose stopper plate bolt

#### Gearshift pedal will not return


- Weak or broken gearshift spindle return spring
- Bent gearshift spindle

## RIGHT CRANKCASE COVER REMOVAL


Drain the engine oil (page 3-9).  
Remove the footpeg bar (page 6-3).

Remove the bolt and kickstarter pedal.


Unhook the brake pedal return spring.  
Loosen the rear brake pedal adjusting nut and lower the brake pedal.



Remove the eight bolts and right crankcase cover.




Remove the gasket and dowel pins.




Remove the clutch adjusting nut, washer and O-ring.

Remove the clutch lifter/adjusting bolt assembly.



## CLUTCH/GEARSHIFT LINKAGE


Check the kickstarter oil seal for damage, replace if necessary.




## CLUTCH

### REMOVAL


Remove the ball retainer and spring.  
Remove the clutch lifter lever.




Remove the oil through and spring.  
Remove the clutch lifter cam plate.



Remove the screws and clutch outer cover and bearing.



Straighten the tab of the lock washer.



Hold the clutch outer with the flywheel holder and remove the lock nut using the special tools as shown.

**TOOLS:**

**Flywheel holder**

07725-004000  
(Equivalent commercially available in U.S.A.)

**Lock nut wrench, 20 × 24 mm**

07716-0020100


**Extension bar**

07716-0020500


(Equivalent commercially available in U.S.A.)



Remove the lock washer B, 14 mm lock washer and clutch assembly.




Remove the primary drive gear.




## CLUTCH/GEARSHIFT LINKAGE

Remove the clutch center guide.



Remove the snap ring and primary driven gear from the mainshaft.

Remove the collar from the crankshaft.




### DISASSEMBLY

Remove the following:


- Set ring
- Clutch plate B
- Clutch disc A
- Clutch disc B
- Clutch disc A
- Free springs
- Clutch plate A

SET RING      PLATES AND DISCS




Remove the clutch center and drive gear outer.

CLUTCH CENTER




Remove the four damper springs.  
Remove the four screws and plain washers.

SCREWS AND WASHERS



DAMPER SPRINGS

Remove the drive plate assembly and clutch springs.




DRIVE PLATE ASSEMBLY

CLUTCH SPRINGS

Remove the clutch weight stopper ring.  
Remove the clutch weight/center ring.

CLUTCH WEIGHT/CENTER RING



STOPPER RING

### INSPECTION

#### Clutch lifter bearing


Turn the inner race of the lifter bearing with your finger.

The bearing should turn smoothly and freely without excessive play.

Also check that the bearing fits tightly in the clutch outer cover.

If necessary replace the bearing.

BEARING




## CLUTCH/GEARSHIFT LINKAGE

### Clutch spring

Measure the clutch spring free length.

**SERVICE LIMIT:** 19.4 mm (0.76 in)



### Clutch disc


Replace the clutch discs if they show signs of scoring or discoloration.

Measure the disc thickness of each disc.

#### SERVICE LIMITS:

**Clutch disc A:** 2.3 mm (0.09 in)


**Clutch disc B:** 3.0 mm (0.12 in)



### Clutch plate

Check each disc plate for warpage on a surface plate using a feeler gauge.

**SERVICE LIMIT:** 0.20 mm (0.008 in)



### Primary drive gear/clutch center guide

Check the primary drive gear and clutch center guide for excessive wear or damage.

Measure the I.D. of the primary drive gear.


**SERVICE LIMIT:** 21.05 mm (0.829 in)

Measure the O.D. and I.D. of the clutch center guide.

#### SERVICE LIMITS:

**I.D.:** 17.04 mm (0.671 in)


**O.D.:** 20.90 mm (0.823 in)



## Crankshaft


Measure the crankshaft O.D at clutch center guide.

**SERVICE LIMIT:** 16.90 mm (0.665 in)




## Drive gear outer/clutch center

Check the drive gear outer and clutch center for excessive wear or damage.




## ASSEMBLY



## CLUTCH/GEARSHIFT LINKAGE

Install the clutch weight/center ring onto the drive plate by aligning the ring end with the plate hole. Install the stopper ring by aligning the ring end with the plate groove.


CLUTCH WEIGHT/CENTER RING



Install the clutch springs onto the clutch outer holes. Install the drive plate assembly into the clutch outer aligning its bosses with the clutch springs.

DRIVE PLATE ASSEMBLY


SPRINGS



Install the plain washers and screws. Tighten the screws in a crisscross pattern in 2-3 steps.


**TORQUE:** 6 N·m (0.6 kgf·m , 4.3 lbf·ft)

SCREWS AND WASHERS



Install the damper springs as shown.


SPRINGS



## CLUTCH/GEARSHIFT LINKAGE


Install the drive gear outer and clutch center.

DRIVE GEAR OUTER



Install the following:  
—Clutch plate A  
—Free springs


SPRINGS



—Clutch disc A  
—Clutch disc B  
—Clutch disc A  
—Clutch plate B


**NOTE:**

- Install the clutch disc A with its flat surface facing the clutch disc B.
- Install the clutch plate B with its chamfered side facing the clutch disc A.



Install the clutch set ring with its chamfered side facing the clutch plate B.

SET RING




## CLUTCH/GEARSHIFT LINKAGE

### INSTALLATION

Install the collar onto the crankshaft.


Install the primary driven gear onto the mainshaft and secure it with the snap ring.



Apply engine oil to the clutch center guide and install it onto the crankshaft.




Install the primary drive gear.




Install the clutch assembly onto the crankshaft.

Install a new 14 mm lock washer by aligning its short tabs with the grooves in the drive plate.



Install the lock washer B with its "OUT SIDE" mark facing out.



Install the lock nut.  
Hold the clutch outer with the flywheel holder and tighten the lock nut to the specified torque using the special tools as shown.


**TOOLS:**

**Flywheel holder**

07725-0040000  
(Equivalent commercially available in U.S.A.)

**Lock nut wrench, 20 × 24 mm  
Extension bar**


07716-0020100  
07716-0020500  
(Equivalent commercially available in U.S.A.)



**TORQUE:** 42 N·m (4.3 kgf·m , 31 lbf·ft)


If the lock nut groove does not align with the lock washer tab, further tighten the lock nut and align.

Bent up the tab of the 14 mm lock washer into the groove of the lock nut.



Clean the inside of the clutch outer and outer cover (page 3-10).


Install the bearing and a new gasket onto the clutch outer cover.




## CLUTCH/GEARSHIFT LINKAGE

Install the clutch outer cover and tighten the screws to the specified torque.


**TORQUE:** 5 N·m (0.5 kgf·m , 3.6 lbf·ft)



Install the clutch lifter cam plate.  
Install the oil through spring and oil through.



Install the spring, ball retainer and clutch lifter lever.  
Install the right crankcase cover (page 9-17).




## GEARSHIFT LINKAGE

### REMOVAL


Remove the clutch and primary driven gear (page 9-4).

*Clean the gearshift spindle end to prevent dirt from entering the crankcase.*


Remove the bolt and gearshift pedal.




Remove the bolt, stopper arm and return spring.




Pull down the gearshift arm, then pull out the gearshift spindle from the crankcase.



Remove the bolt and shift cam plate.




Remove the dowel pins and gearshift drum pins.



## CLUTCH/GEARSHIFT LINKAGE


### INSPECTION

Check the gearshift spindle for bends or other damage.




### INSTALLATION

Install the four gearshift drum pins and two dowel pins.




Install the cam plate and tighten the bolt to the specified torque.

**TORQUE:** 17 N·m (1.7 kgf·m, 12 lbf·ft)




Install the gearshift spindle into the crankcase by aligning the return spring ends with the spring pin while pushing down the gearshift arm and set the gearshift arm to the shift drum pins.




Install the return spring and stopper arm as shown and tighten the bolt to the specified torque.

**TORQUE:** 13 N·m (1.3 kgf·m , 9 lbf·ft)




Install the gearshift pedal so that it is same height as the footpeg.  
Install the pinch bolt and tighten it.

Install the primary driven gear and clutch assembly (page 9-12).




## **RIGHT CRANKCASE COVER INSTALLATION**

Install the clutch lifter plate/adjusting bolt into the right crankcase cover by aligning its pin with the hole in the crankcase cover.




Coat a new O-ring with engine oil and install it into the cover groove properly.  
Install the washer and lock nut.




## CLUTCH/GEARSHIFT LINKAGE

Install the dowel pins and a new gasket.




Install the right crankcase cover.  
Install and tighten the eight cover bolts in a crisscross pattern several steps.



Install the kickstarter pedal as shown and tighten the bolt.  
Hook the return spring to the brake pedal and spring holding pin as shown.

Install the footpeg bar (page 6-4).  
Adjust the brake pedal free play (page 3-15).

Pour the recommended engine oil (page 3-9).  
Adjust the clutch (page 3-16).




---

MEMO

---

# ALTERNATOR/CAM CHAIN TENSIONER



# 10. ALTERNATOR/CAM CHAIN TENSIONER

SERVICE INFORMATION	10-1	CAM CHAIN TENSIONER	10-4
TROUBLESHOOTING	10-1	STATOR/FLYWHEEL INSTALLATION	10-6
FLYWHEEL/STATOR REMOVAL	10-2		

## SERVICE INFORMATION

### GENERAL

- This section covers service of the flywheel, alternator and cam chain tensioner. All service can be done with the engine installed in the frame.
- Refer to section 14 for alternator stator inspection.

### SPECIFICATIONS

Unit: mm (in)

ITEM		STANDARD	SERVICE LIMIT
Cam chain tensioner	Push rod O.D.	11.985 – 12.000 (0.4718 – 0.4724)	11.94 (0.470)
	Spring free length	111.3 (4.38)	100 (3.9)

### TORQUE VALUES

- Flywheel nut 41 N·m (4.2 kgf·m , 30 lbf·ft)
- Cam chain tensioner sealing bolt 23 N·m (2.3 kgf·m , 17 lbf·ft)
- Cam chain tensioner pivot bolt 16 N·m (1.6 kgf·m , 12 lbf·ft)

### TOOLS

- Universal holder 07725 – 0030000
- Flywheel puller 07933 – GE00000 Not available in U.S.A. or 07933 – 0010000 U.S.A. only

## TROUBLESHOOTING

### Excessive engine noise

- Worn or damaged cam chain tensioner
- Clogged one-way valve
- Weak or damaged cam chain tensioner spring


### Loose cam chain

- Weak or damaged cam chain tensioner spring
- Improper push rod operation
- Clogged one-way valve
- Air in cam chain tensioner chamber


## ALTERNATOR/CAM CHAIN TENSIONER

### FLYWHEEL/STATOR REMOVAL


Disconnect the alternator and ignition pulse generator connectors.



Remove the bolt and gearshift pedal.




Remove the three bolts and left crankcase cover.



Hold the flywheel using the universal holder and remove the flywheel nut.

**TOOL:**  
**Universal holder**                      07725-0030000

Remove the washer.



## ALTERNATOR/CAM CHAIN TENSIONER

Remove the flywheel using the special tool.


**TOOL:**

**Flywheel puller**


07933-GE00000  
(Not available in U.S.A.)

**Flywheel puller**


07933-0010000  
(U.S.A. only)




Remove the woodruff key.



Remove the bolt and wire clamp.  
Release the wire grommet from the crankcase groove.




Remove the four mounting bolts and wire clamp, and the ignition pulse generator and stator as an assembly.




## ALTERNATOR/CAM CHAIN TENSIONER

Drain the engine oil (page 3-9).

Remove the screws and stator base.



Remove the O-rings.




## CAM CHAIN TENSIONER


### REMOVAL

Remove the stator base (page 10-2).

Remove the sealing bolt, tensioner spring and push rod.




Remove the pivot bolt, tensioner arm and tensioner roller.



## INSPECTION


Measure the tensioner spring free length.

**SERVICE LIMIT:** 100 mm (3.9 in)



Check the push rod for wear or damage.  
Measure the push rod O.D.

**SERVICE LIMIT:** 11.94 mm (0.470 in)




## INSTALLATION

Install the cam chain tensioner roller, tensioner arm and pivot bolt.

Tighten the pivot bolt to the specified torque.

**TORQUE:** 16 N·m (1.6 kgf·m , 12 lbf·ft)




Check the sealing washer is in good condition, replace if necessary.

Install the push rod, spring, washer and sealing bolt.


Tighten the sealing bolt to the specified torque.

**TORQUE:** 23 N·m (2.3 kgf·m , 17 lbf·ft)




## ALTERNATOR/CAM CHAIN TENSIONER

Remove the crankcase sealing bolt and washer.  
Fill the push rod with 1–2 cm<sup>3</sup> of engine oil  
through the filler hole.




Check the sealing washer is in good condition and  
install the sealing washer and bolt.  
Tighten the bolt securely.



## STATOR/FLYWHEEL INSTALLATION

Check the stator base oil seal for damage, replace if  
necessary.  
Apply engine oil to the lip of the oil seal.


Apply engine oil to new O-rings, install them into  
the crankcase grooves and stator base groove.



Install the stator base and tighten the screws se-  
curely.


### CAUTION:

*Be careful not to damage the oil seal lips.*




## ALTERNATOR/CAM CHAIN TENSIONER


Install the stator and ignition pulse generator with the wire clamp and tighten the bolts securely.



Set the wire grommet into the crankcase groove. Install the wire clamp and tighten the bolt.




Clean any oil from the tapered portion of the crankshaft and flywheel. Install the woodruff key into the crankshaft.



Install the flywheel by aligning the key way in the flywheel with the woodruff key on the crankshaft.

Install the washer and flywheel nut.




## ALTERNATOR/CAM CHAIN TENSIONER

Hold the flywheel using the universal holder and tighten the nut to the specified torque.


**TOOL:**

Universal holder                      07725-0030000

**TORQUE:** 41 N·m (4.2 kgf·m , 30 lbf·ft)



Install the left crankcase cover and tighten the three bolts.



LEFT CRANKCASE COVER

Install the gearshift pedal so that it is same height as the footpeg.  
Install the pinch bolt and tighten it.



GEARSHIFT PEDAL

Connect the ignition pulse generator and alternator connectors.




CONNECTORS

---

**MEMO**

# CRANKSHAFT/TRANSMISSION/KICKSTARTER



# 11. CRANKSHAFT/TRANSMISSION/KICKSTARTER

SERVICE INFORMATION	11-1	TRANSMISSION	11-6
TROUBLESHOOTING	11-2	KICKSTARTER	11-12
CRANKCASE SEPARATION	11-3	CRANKCASE ASSEMBLY	11-14
CRANKSHAFT	11-4		

## SERVICE INFORMATION

### GENERAL

- The crankcase must be separated to service the crankshaft, transmission and kickstarter.
- The following parts must be removed before separating the crankcase.
  - Alternator/cam chain tensioner (Section 10)
  - Clutch/gearshift linkage (Section 9)
  - Cylinder head (Section 7)
  - Cylinder/piston (Section 8)
  - Engine (Section 6)
  - Oil pump (Section 4)

### SPECIFICATIONS

Unit: mm (in)

ITEM		STANDARD	SERVICE LIMIT
Crankshaft	Side clearance	0.010 – 0.350 (0.0004 – 0.0138)	0.60 (0.024)
	Radial clearance	0 – 0.012 (0 – 0.0005)	0.05 (0.002)
	Runout	—	0.10 (0.004)
Transmission	Gear I.D.	M2	17.016 – 17.043 (0.6699 – 0.6710)
		C1	23.020 – 23.053 (0.9063 – 0.9076)
		C3	20.020 – 20.053 (0.7882 – 0.7895)
	Bushing O.D.	C1	22.979 – 23.000 (0.9047 – 0.9055)
	Bushing I.D.	C1	20.000 – 20.021 (0.7874 – 0.7882)
	Gear-to-bushing clearance	C1	0.020 – 0.074 (0.0008 – 0.0029)
	Mainshaft O.D.	M2	16.966 – 16.984 (0.6680 – 0.6687)
	Countershaft O.D.	C1	19.959 – 19.980 (0.7858 – 0.7866)
	Gear-to-shaft clearance	M2	0.032 – 0.077 (0.0013 – 0.0030)
	Gear bushing-to-shaft clearance	C1	0.020 – 0.062 (0.0008 – 0.0024)
Shift fork	I.D.	34.075 – 34.100 (1.3415 – 1.3425)	34.14 (1.344)
	Claw thickness	4.86 – 4.94 (0.191 – 0.194)	4.60 (0.181)
	Shift drum O.D.	33.950 – 33.975 (1.3366 – 1.3376)	33.93 (1.336)

11

### TORQUE VALUES

Shift drum bolt

12 N·m (1.2 kgf·m, 9 lbf·ft)

## CRANKSHAFT/TRANSMISSION/KICKSTARTER

---

### TOOLS

Driver	07749-0010000
Attachment, 37 × 40 mm	07746-0010200
Pilot, 17 mm	07746-0040400

### TROUBLESHOOTING

#### Hard to shift

- Incorrect clutch adjustment
- Bent shift fork
- Bent fork claw
- Damaged shift drum cam groove
- Incorrect transmission oil weight

#### Transmission jumps out of gear

- Worn gear dogs and slots
- Bent fork shaft
- Broken shift drum stopper

#### Excessive noise

- Worn crankshaft big end bearing
- Worn crankshaft journal bearing

## CRANKCASE SEPARATION

**NOTE:**

Refer to Service Information (page 11-1) for removal of necessary parts before separating the crankcase.

Remove the snap ring from the kickstarter spindle.





Unhook the return spring and remove the retainer and return spring.

Remove the rubber cap.

Remove the shift drum bolt and washer.


Remove the cam chain.

Loosen the seven crankcase bolts in a crisscross pattern in 2-3 steps and remove them.




## CRANKSHAFT/TRANSMISSION/KICKSTARTER

Place the crankcase with the left side down.  
Separate the right and left crankcase halves.




Remove the gasket and dowel pins.




## CRANKSHAFT

### REMOVAL

Remove the crankshaft from the left crankcase.




If necessary, remove the cam chain guide spindle and guide sprocket.



## INSPECTION


Measure the connecting rod big end side clearance with a feeler gauge.

**SERVICE LIMIT:** 0.60 mm (0.024 in)




Measure the connecting rod big end radial clearance at symmetrical points as shown.

**SERVICE LIMIT:** 0.05 mm (0.002 in)




Turn the outer race of the crankshaft bearing with your finger.  
The bearing should turn smoothly and quietly.  
Also check that the inner race of the bearing fits tightly on the crankshaft.



Check the timing sprocket for wear or damage.


If you replacing the timing sprocket, align the center of the sprocket teeth with the center of woodruff key groove as shown.



## CRANKSHAFT/TRANSMISSION/KICKSTARTER


Place the crankshaft on a stand or V-blocks and measure the runout using a dial gauge. The measuring locations are shown in the illustration.

**SERVICE LIMIT:** 0.10 mm (0.004 in)




### INSTALLATION

Install the guide sprocket and guide spindle.



Pour 1–2 cm<sup>3</sup> of engine oil into the connecting rod big end bearing. Install the crankshaft into the left crankcase, being careful not to interfere the connecting rod with the crankcase. Assemble the crankcase halves (page 11-14).




## TRANSMISSION

### REMOVAL


Remove the kickstarter spindle (page 11-12).

Remove the mainshaft, countershaft and shift drum as an assembly.



**TRANSMISSION DISASSEMBLY**

Disassemble the mainshaft, countershaft and shift drum.



**TRANSMISSION INSPECTION**

Check the gear dogs, dog holes and teeth for abnormal wear or lack of lubrication. Measure the I.D. of each gear.

**SERVICE LIMITS:**

- M2: 17.10 mm (0.673 in)
- C1: 23.10 mm (0.909 in)
- C3: 20.10 mm (0.791 in)

Measure the I.D. and O.D. of C1 gear bushing.



**SERVICE LIMITS:**

- O.D.: 22.93 mm (0.903 in)
- I.D.: 20.08 mm (0.791 in)

Calculate the C1 gear-to-bushing clearance.

**SERVICE LIMIT:** 0.10 mm (0.004 in)

Check the shifter groove of the shifter gear for excessive wear or damage.



Measure the O.D. of the mainshaft and countershaft.

**SERVICE LIMITS:**


- At M2 gear: 16.95 mm (0.667 in)
- At C1 gear: 19.94 mm (0.785 in)

Calculate the M2 gear-to-shaft clearance.

**SERVICE LIMIT:** 0.10 mm (0.004 in)


Calculate the C1 gear bushing-to-shaft clearance.


**SERVICE LIMIT:** 0.10 mm (0.004 in)



**TRANSMISSION ASSEMBLY**


Assembly is in the reverse order of disassembly.

 : Gear sliding surface, gear teeth and shifter groove



**GEARSHIFT DRUM DISASSEMBLY**


Remove the guide pin clips.  
Remove the guide pins, then remove the shift forks.



Inspect the shift drum grooves for wear or damage.


Measure the O.D. of the shift drum.

**SERVICE LIMIT:** 33.93 mm (1.336 in)



Measure the shift fork I.D.

**SERVICE LIMIT:** 34.14 mm (1.344 in)




Measure the shift fork claw thickness.

**SERVICE LIMIT:** 4.60 mm (0.181 in)




**SHIFT DRUM ASSEMBLY**



## CRANKSHAFT/TRANSMISSION/KICKSTARTER

Apply engine oil to the shift drum outer surface.  
Install the shift forks onto the gearshift drum.  
Install the guide pins and secure them with the clips.




If the washer has been removed, install a new washer and bend the tab to lock the washer.




### TRANSMISSION BEARING REPLACEMENT

Turn the inner race of each bearing with your finger.  
The bearings should turn smoothly and quietly.  
Also check that the bearing outer race fits tightly in the crankcase.  
Remove and discard the bearing if the race does not turn smoothly, quietly, or fits loosely in the crankcase.



Remove the countershaft oil seal.



Drive the mainshaft bearing out of the right crankcase.

## RIGHT CRANKCASE:



Drive the countershaft bearing out of the left crankcase.


## LEFT CRANKCASE:




Drive new bearings into the crankcases using the special tools as shown.

### TOOLS:

Driver	07749-0010000
Attachment, 37 × 40 mm	07746-0010200
Pilot, 17 mm	07746-0040400



Apply engine oil to a new countershaft oil seal lip. Install the countershaft oil seal.




## CRANKSHAFT/TRANSMISSION/KICKSTARTER

### TRANSMISSION INSTALLATION

Apply clean engine oil to the transmission gears and shift drum.


Set the right fork into the M3 gear and the left fork into the C2 gear to assemble the mainshaft, countershaft and shift drum as shown.



Install the mainshaft, countershaft and shift drum as an assembly into the left crankcase.

Rotate the shift drum to check the transmission operation.


Install the kickstarter spindle (page 11-14).



## KICKSTARTER

### REMOVAL


Remove the kickstarter spindle from the right crankcase.




### DISASSEMBLY

Remove the washer.

Remove the snap ring and starter ratchet/spring.




Remove the snap ring, washer and starter pinion gear.



**INSPECTION**


Check the kickstarter spindle for bending.  
Check the friction spring for fatigue.

Check each part for wear or damage, replace if necessary.



**ASSEMBLY**

Assembly is in the reverse order of disassembly.




## CRANKSHAFT/TRANSMISSION/KICKSTARTER

### INSTALLATION

Install the kickstarter spindle by aligning its friction spring with the groove in the left crankcase as shown.

Assemble the crankcase halves.



### CRANKCASE ASSEMBLY



Clean the crankcase mating surfaces before assembling.

#### NOTE:

Dress the surfaces with an oil stone if necessary to correct any minor roughness or irregularities.


Install the dowel pins and a new gasket onto the left crankcase.

*Make sure that the gasket stays in place.* Install the right crankcase over the left crankcase.



Install the seven bolts with the clamp and tighten them in a crisscross pattern in 2-3 steps.


Apply engine oil to the cam chain and install it.




## CRANKSHAFT/TRANSMISSION/KICKSTARTER

Install the washer and bolt to the shift drum, then tighten the bolt to the specified torque.

**TORQUE:** 12 N·m (1.2 kgf·m , 9 lbf·ft)




Install the rubber cap.




Install the return spring and retainer onto the kickstarter spindle.  
Temporarily install the kickstarter pedal.


Install the spring ends onto the retainer and crankcase lug as shown and press the retainer to set its edge against the stepped part of the crankcase while turning the pedal counterclockwise.



Install the snap ring into the groove in the kickstarter spindle securely.



# FRONT WHEEL/BRAKE/SUSPENSION/STEERING



# 12. FRONT WHEEL/BRAKE/SUSPENSION/STEERING

SERVICE INFORMATION	12-1	FRONT BRAKE	12-10
TROUBLESHOOTING	12-2	FORK	12-12
HANDLEBAR	12-3	STEERING STEM	12-15
FRONT WHEEL	12-5		

## SERVICE INFORMATION

### GENERAL

#### ▲WARNING

*A contaminated brake drum or shoe reduces stopping power. Discard contaminated shoes and clean a contaminated drum with a high quality brake degreasing agent.*

- When servicing the front wheel, brake, fork or steering stem, support the motorcycle using a safety stand or hoist.

### SPECIFICATIONS

Unit: mm (in)

ITEM		STANDARD	SERVICE LIMIT
Minimum tire tread depth		—————	3.0 (0.12)
Cold tire pressure		100 kPa (1.0 kgf/cm <sup>2</sup> , 15 psi)	—————
Axle runout		—————	0.20 (0.008)
Wheel rim-to-hub distance		6.3 ± 1.0 (0.25 ± 0.04)	—————
Wheel rim runout	Radial	—————	2.0 (0.08)
	Axial	—————	2.0 (0.08)
Brake	Brake lever free play	10 – 20 mm (3/8 – 13/16 in)	—————
	Brake drum I.D.	80 (3.1)	80.5 (3.17)
	Brake lining thickness	3.5 (0.14)	2.0 (0.08)
Fork	Spring free length	160.8 (6.33)	158.3 (6.23)

12

### TORQUE VALUES

Handlebar mounting nut	20 N·m (2.0 kgf·m, 14 lbf·ft)	U-nut
Engine stop switch holder screw	3 N·m (0.3 kgf·m, 2.2 lbf·ft)	
Brake lever pivot bolt	3 N·m (0.3 kgf·m, 2.2 lbf·ft)	
Brake lever pivot nut	3 N·m (0.3 kgf·m, 2.2 lbf·ft)	
Spoke nipple	2 N·m (0.2 kgf·m, 1.4 lbf·ft)	
Front axle nut	47 N·m (4.8 kgf·m, 35 lbf·ft)	U-nut
Front brake arm pinch bolt	6 N·m (0.6 kgf·m, 4.3 lbf·ft)	ALOC bolt
Fork protector bolt	10 N·m (1.0 kgf·m, 7 lbf·ft)	
Steering stem nut	74 N·m (7.5 kgf·m, 54 lbf·ft)	
Steering stem top thread	See page 12-17	

## FRONT WHEEL/BRAKE/SUSPENSION/STEERING

---

### TOOLS

Spoke wrench, 4.1 × 4.5 mm	07701-0020100	Commercially available in U.S.A.
Bearing remover shaft	07746-0050100	Commercially available in U.S.A.
Bearing remover head, 12 mm	07746-0050300	
Driver	07749-0010000	
Attachment, 32 × 35 mm	07746-0010100	
Pilot, 12 mm	07746-0040200	
Pin spanner	07702-0020001	
Ball race remover	07944-1150001	
Attachment, 37 × 40 mm	07746-0010200	
Steering stem driver	07946-GC40000	or Steering stem driver 07946-MB00000 with Steering stem driver attachment 07946-GC4000A (U.S.A. only)

### TROUBLESHOOTING

#### Hard steering

- Faulty or damaged steering head bearings
- Insufficient tire pressure
- Steering stem top thread too tight

#### Steers to one side or does not track straight

- Bent fork
- Bent axle
- Wheel installed incorrectly
- Faulty steering head bearings
- Bent frame
- Worn wheel bearing
- Worn swingarm pivot components

#### Front wheel wobbling

- Bent rim
- Worn front wheel bearings
- Faulty tire
- Unbalanced tire and wheel

#### Wheel turns hard

- Faulty wheel bearing
- Bent front axle
- Brake drag

#### Soft suspension

- Weak fork springs
- Tire pressure too low

#### Hard suspension

- Bent fork tubes

#### Front suspension noisy

- Damaged or bent fork tubes
- Loose fork fasteners

#### Improper brake performance


- Incorrect adjustment of lever
- Contaminated brake shoes
- Worn brake shoes
- Worn brake cam
- Worn brake drum
- Improperly engaged brake arm serrations

## HANDLEBAR


### REMOVAL

Remove the fuel tank breather tube from the number plate and the number plate from the steering stem nut.


Remove the wire bands.




Remove the two screws and engine stop switch/throttle housing from the handlebar.



Disconnect the throttle cable and remove the throttle grip.



Remove the left handlebar grip.




## FRONT WHEEL/BRAKE/SUSPENSION/STEERING

Remove the two nuts and handlebar.

### INSTALLATION

Install the handlebar into the fork top bridge and tighten the mounting nuts.

**TORQUE:** 20 N·m (2.0 kgf·m, 14 lbf·ft)




Clean the inside surface of the left handlebar grip and the outside surface of the left handlebar. Apply Honda Bond A or equivalent to the inside surface of the left handlebar grip and to the outside surface of the left handlebar. Wait 3–5 minutes and install the grip.

Rotate the grip for even application of the adhesive.


**NOTE:**

Allow the adhesive to dry for an hour before using.



Apply grease to the throttle grip pipe flange and install the throttle grip onto the right handlebar.


Connect the throttle cable to the throttle grip pipe flange.



Install the engine stop switch/throttle housing onto the handlebar, aligning the mating surface with the punch mark on the handlebar.

Tighten the forward screw first, then the rear screw.


**TORQUE:** 3 N·m (0.3 kgf·m, 2.2 lbf·ft)



Secure the engine stop switch wire with the wire bands properly.

Install the number plate over the steering stem nut and insert the breather tube into the hole in the number plate.

Check the throttle grip operation and free play (page 3-4).



## FRONT WHEEL

### REMOVAL



#### ▲WARNING

*A contaminated brake drum or shoe reduces stopping power. Discard contaminated shoes and clean a contaminated drum with a high quality brake degreasing agent.*


Support the motorcycle securely using a safety stand or a hoist.

Remove the brake cable from the cable holder on the fork protector.  
Remove the two bolts and fork protector.

Disconnect the brake cable from the brake arm.  
Remove the axle nut, axle and front wheel.



Remove the side collar and the brake panel from the wheel hub.




## FRONT WHEEL/BRAKE/SUSPENSION/STEERING

### INSPECTION

#### Axle

Set the axle in V-blocks and measure the runout. Actual runout is 1/2 the total indicator reading.

**SERVICE LIMIT:** 0.20 mm (0.008 in)




#### Wheel bearing

Turn the inner race of each bearing with your finger. The bearings should turn smoothly and quietly. Also check that the bearing outer race fits tightly in the hub.

*Always replace the bearings in pairs.*

Remove and discard the bearings if they do not turn smoothly, quietly, or if they fit loosely in the hub.



#### Wheel rim runout

Check the rim runout by placing the wheel in a turning stand.


Spin the wheel by hand, and read the runout using a dial indicator.

Actual runout is 1/2 the total indicator reading.

#### SERVICE LIMITS:


**Radial:** 2.0 mm (0.08 in)

**Axial:** 2.0 mm (0.08 in)



### DISASSEMBLY

Remove the dust seal.




Install the bearing remover head into the bearing. From the opposite side, install the bearing remover shaft and drive the bearing out of the wheel hub. Remove the distance collar and drive out the other bearing.

**TOOLS:**

- Bearing remover head, 12 mm 07746-0050300  
(Equivalent commercially available in U.S.A.)
- Bearing remover shaft 07746-0050100  
(Equivalent commercially available in U.S.A.)



**ASSEMBLY**




**CAUTION:**

*Never install the old bearings. Once the bearings have been removed, the bearings must be replaced with new ones.*

Pack each wheel bearing cavities with grease. Drive in a new left bearing squarely with its sealed side facing out. Install the distance collar and drive in a new right bearing using the same tools.

**TOOLS:**

- Driver 07749-0010000
- Attachment, 32 × 35 mm 07746-0010100
- Pilot, 12 mm 07746-0040200



## FRONT WHEEL/BRAKE/SUSPENSION/STEERING

### Wheel center adjustment

Place the rim on the work bench.  
Place the hub with the right side down and begin lacing with new spokes.  
Adjust the hub position so that the distance from the hub left end surface to the side of rim is  $6.3 \pm 1$  mm ( $0.25 \pm 0.04$  in) as shown.


### TOOL:

**Spoke wrench, 4.1 × 4.5 mm** 07701-0020100  
(Equivalent commercially available in U.S.A.)

**TORQUE:** 2 N·m (0.2 kgf·m, 1.4 lbf·ft)


Check the rim runout (page 12-8).

Apply grease to a new dust seal lips, then install it into the right wheel hub.




## INSTALLATION

Install the brake panel into the left wheel hub.





Install the side collar into the right wheel hub.



## FRONT WHEEL/BRAKE/SUSPENSION/STEERING


Install the front wheel between the fork legs while aligning the brake panel groove with the boss on the left fork tube.



Apply a thin layer of grease to the front axle surface. Install the front axle from the right side. Hold the axle and temporarily tighten the axle nut.

Install the spring and joint pin and connect the brake cable. Install the adjusting nut.

Adjust the front brake lever free play (page 3-14).



With the front brake applied, pump the fork up and down several times to seat the axle and check brake operation.

Tighten the axle nut to the specified torque.


**TORQUE:** 47 N·m (4.8 kgf·m , 35 lbf·ft)



Install the fork protector and tighten the bolts.

**TORQUE:** 10 N·m (1.0 kgf·m , 7 lbf·ft)

Install the brake cable into the cable holder.



**FRONT BRAKE**

**REMOVAL**

Remove the brake panel from the front wheel (page 12-5).



**INSPECTION**

Measure the front brake drum I.D.

**SERVICE LIMIT:** 80.5 mm (3.17 in)


Measure the brake lining thickness.

**SERVICE LIMIT:** 2.0 mm (0.08 in)




**DISASSEMBLY**

Remove the spring and brake shoes.




Remove the nut, bolt and brake arm.


Remove the wear indicator, dust seal and brake cam.



ASSEMBLY




Apply grease to the brake cam spindle.  
Install the brake cam into the brake panel.



Apply oil to a new dust seal and install it onto the brake panel.


Install the wear indicator onto the brake cam by aligning its wide tooth with the wide groove in the brake cam.



## FRONT WHEEL/BRAKE/SUSPENSION/STEERING

Install the brake arm by aligning the punch marks on the arm and brake cam.  
Install a new brake arm pinch bolt and nut as shown and tighten it to the specified torque.


**TORQUE:** 6 N·m (0.6 kgf·m , 4.3 lbf·ft)



Apply grease to the anchor pin and brake cam sliding surfaces.  
Install the brake shoes and spring as shown.  
Wipe any excess grease of the brake cam and anchor pin.

### INSTALLATION

Install the front wheel (page 12-8).



## FORK



### DISASSEMBLY

Remove the front wheel (page 12-5).

Loosen the brake cable nut and remove the brake cable from the fork slider.

Remove the dust seal from the fork outer tube by sliding it down.  
Remove the stopper ring.

Remove the fork top bolt and washer and pull the fork slider down to remove the fork assembly.




## FRONT WHEEL/BRAKE/SUSPENSION/STEERING

Drive out the spring pin, using a 4 mm pin driver.


Remove the following from the fork slider:

- fork spring/spring holders
- slider piston
- slider guide
- back up ring
- stopper ring
- dust seal




### INSPECTION

Visually inspect each part for excessive wear or damage.




Measure the fork spring free length.

**SERVICE LIMIT:** 158.3 mm (6.23 in)




### ASSEMBLY



## FRONT WHEEL/BRAKE/SUSPENSION/STEERING

Install the following onto the fork slider:



- new dust seal (apply grease to the seal lips)
- stopper ring (with the chamfered side facing up)
- back up ring
- slider guide (apply 5–6 g of grease to the slider guide sliding surface of the fork slider)



Install the slider piston and fork spring/holders as shown.

Align the pin holes in the piston, fork slider and spring holder so that the locating pin on the upper spring holder is facing inside of the fork slider and drive the spring pin to secure them, using a 4 mm pin driver.


Be sure that the spring pin do not project out of the piston outer surface.



Apply 5–6 g of grease to the slider guide outer groove.


Pack the fork spring with 14 g of grease.

Install the fork assembly by aligning the locating pin with the groove in the outer tube.



Install the fork top bolt and washer and tighten it.

Wipe any excess grease of the outer tube.




Install the stopper ring into the groove in the outer tube properly.

Install the dust seal over the outer tube.

Wipe any excess grease of the fork slider.

Install the brake cable onto the fork slider and secure it by tightening the cable nut.

Install the front wheel (page 12-10).




## STEERING STEM

### REMOVAL

Remove the following:

- Number plate (page 2-3)
- Handlebar (page 12-3)
- Front wheel (page 12-5)
- Front fender (page 2-3)
- Steering stem nut and washer
- Fork top bolts and washers
- Top bridge




Remove the steering stem top thread using the special tool.

#### TOOL:


Pin spanner

07702-0020001



Remove the following:

- Upper bearing inner race
- Upper bearing
- Steering stem
- Lower bearing



## FRONT WHEEL/BRAKE/SUSPENSION/STEERING

### BEARING REPLACEMENT


*Always replace the bearings and races as a set.* Drive out the upper and lower bearing outer races using the special tool.

**TOOL:**  
**Ball race remover** 07944-1150001



Drive new upper and lower bearing outer races into the steering head pipe using the special tools as shown.

**TOOLS:**  
**Driver** 07749-0010000  
**Attachment, 37 × 40 mm** 07746-0010200



Temporarily install the steering stem nut onto the stem to prevent the threads from being damaged when removing the lower bearing inner race from the stem.


Remove the lower bearing inner race with a chisel or equivalent tool, being careful not to damage the stem.

Remove the dust seal and washer.




Install the washer over the steering stem. Apply grease to a new dust seal lips and install it over the steering stem. Install a new lower bearing inner race using a special tool and a hydraulic press.

**TOOL:**  
**Steering stem driver** 07946-GC40000  
**Steering stem driver** 07946-MB00000 with  
**Steering stem driver attachment**  
07946-GC4000A  
(U.S.A. only)




INSTALLATION



Apply grease to upper and lower bearings and races.  
Install the lower bearing onto the lower bearing race.

Insert the steering stem into the steering head pipe.

Install upper bearing, inner race and top thread.



Hold the steering stem and tighten the stem top thread to the initial torque.

**TORQUE:** 25 N·m (2.5 kgf·m , 18 lbf·ft)



## FRONT WHEEL/BRAKE/SUSPENSION/STEERING

Move the steering stem right and left, lock-to-lock several times to seat the bearings.  
Loosen the top thread.  
Retighten the top thread to the specified torque.

**TORQUE:** 3 N·m (0.3 kgf·m , 2.2 lbf·ft)




Install the top bridge.  
Install the stem nut and fork top bolts with the washers and tighten them.

**TORQUE: Stem nut:** 74 N·m (7.5 kgf·m , 54 lbf·ft)

Make sure that the steering stem moves smoothly, without play or binding.

Install the following:


- Front fender (page 2-3)
- Front wheel (page 12-8)
- Handlebar (page 12-4)
- Number plate (page 2-3)



---

MEMO

# REAR WHEEL/BRAKE/SUSPENSION



# 13. REAR WHEEL/BRAKE/SUSPENSION

SERVICE INFORMATION	13-1	SHOCK ABSORBER	13-10
TROUBLESHOOTING	13-2	SWINGARM	13-12
REAR WHEEL	13-3	BRAKE PEDAL	13-13
REAR BRAKE	13-8		

## SERVICE INFORMATION

### GENERAL

#### ▲WARNING

*A contaminated brake drum or shoe reduces stopping power. Discard contaminated shoes and clean a contaminated drum with a high quality brake degreasing agent.*

- When servicing the rear wheel, support the motorcycle using a safety stand or hoist.

### SPECIFICATIONS

Unit: mm (in)

ITEM	STANDARD	SERVICE LIMIT	
Minimum tire tread depth	—————	3.0 (0.12)	
Cold tire pressure	125 kPa (1.25 kgf/cm <sup>2</sup> , 18 psi)	—————	
Axle runout	—————	0.20 (0.008)	
Wheel rim-to-hub distance	25 ± 1.0 (1.0 ± 0.04)	—————	
Wheel rim runout	Radial	2.0 (0.08)	
	Axial	2.0 (0.08)	
Drive chain	Size/link	DID420MBK1/78	
	Slack	15–25 (9/16–1)	
Brake	Brake pedal free play	10–20 (3/8–13/16)	
	Brake drum I.D.	80 (3.1)	80.5 (3.17)
	Brake lining thickness	3.5 (0.14)	2.0 (0.08)

13

### TORQUE VALUES

Spoke nipple	2 N·m (0.2 kgf·m, 1.4 lbf·ft)	
Rear axle nut	47 N·m (4.8 kgf·m, 35 lbf·ft)	U-nut
Driven sprocket nut	32 N·m (3.3 kgf·m, 24 lbf·ft)	U-nut
Rear brake arm pinch bolt	6 N·m (0.6 kgf·m, 4.3 lbf·ft)	ALOC bolt
Swingarm pivot nut	39 N·m (4.0 kgf·m, 29 lbf·ft)	Apply grease to the seating surface/ U-nut
Shock absorber mounting nut	34 N·m (3.5 kgf·m, 25 lbf·ft)	U-nut
Drive chain slider nut	12 N·m (1.2 kgf·m, 9 lbf·ft)	U-nut

### TOOLS

Spoke wrench, 4.1 × 4.5 mm	07701–0020100	Equivalent commercially available in U.S.A.
Bearing remover shaft	07746–0050100	Equivalent commercially available in U.S.A.
Bearing remover head, 12 mm	07746–0050300	
Driver	07749–0010000	
Attachment, 32 × 35 mm	07746–0010100	
Pilot, 12 mm	07746–0040200	

## REAR WHEEL/BRAKE/SUSPENSION

---

### TROUBLESHOOTING

#### Soft suspension

- Weak shock absorber spring
- Oil leakage from damper unit
- Tire pressure too low

#### Hard suspension

- Bent damper rod
- Damaged swingarm pivot bushings
- Bent swingarm pivot
- Tire pressure too high

#### Steers to one side or does not track straight

- Bent rear axle
- Axle alignment/chain adjustment not equal on both sides

#### Rear wheel wobbling


- Bent rim
- Worn rear wheel bearings
- Faulty tire
- Unbalanced tire and wheel
- Tire pressure too low
- Faulty swingarm pivot bushings

## REAR WHEEL

### REMOVAL

Support the motorcycle securely using a hoist or equivalent and raise the rear wheel off the ground.


Remove the rear brake adjusting nut and disconnect the rear brake rod from the brake arm, and remove the joint pin and spring.




Loosen the drive chain adjuster lock nuts and adjusting nuts.  
Remove the axle nut and left chain adjuster.

Push the rear wheel forward and derail the drive chain from the driven sprocket.


Remove the axle from the left side and remove the rear wheel.



Remove the left side collar from the left wheel hub.



Remove the brake panel from the right wheel hub.




## REAR WHEEL/BRAKE/SUSPENSION

### INSPECTION

#### Axle

Place the axle in V-blocks and measure the runout. Actual runout is 1/2 the total indicator reading.


**SERVICE LIMIT:** 0.20 mm (0.008 in)



#### Wheel bearing

Turn the inner race of each bearing with your finger. Bearings should turn smoothly and quietly. Also check that the bearing outer race fits tightly in the hub.

*Replace the wheel bearings in pairs.* Remove and discard the bearings if the races do not turn smoothly and quietly, or if they fit loosely in the hub.




#### Wheel rim runout

Check the rim runout by placing the wheel in a turning stand.

Spin the wheel slowly and read the runout using a dial indicator.

Actual runout is 1/2 the total indicator reading.

**SERVICE LIMITS:** Radial: 2.0 mm (0.08 in)  
Axial: 2.0 mm (0.08 in)




#### Driven sprocket

Check the condition of the final driven sprocket teeth.

Replace the sprocket if worn or damaged.


#### NOTE:

- If the final driven sprocket requires replacement, inspect the drive chain and drive sprocket.
- Never install a new drive chain on a worn sprocket or a worn chain on new sprockets. Both chain and sprocket must be in good condition or the replacement chain or sprocket will wear rapidly.



**DISASSEMBLY**

Remove the nuts, bolts and driven sprocket.  
Remove the left dust seal.




**Wheel bearing removal**

Install the bearing remover head into the bearing.  
From the opposite side install the bearing remover shaft and drive the bearing out of the wheel hub.  
Remove the distance collar and drive out the other bearing.


**TOOLS:**

**Bearing remover head, 12 mm** 07746-0050300  
(Equivalent commercially available in U.S.A.)

**Bearing remover shaft** 07746-0050100  
(Equivalent commercially available in U.S.A.)



**ASSEMBLY**



## REAR WHEEL/BRAKE/SUSPENSION

### Wheel bearing installation

#### CAUTION:



*Never install the old bearings, once the bearings has been removed, the bearing must be replaced with new ones.*

Pack each wheel bearing cavity with grease.  
Drive in a new right bearing squarely with the sealed side facing up using the special tools as shown.

#### TOOLS:

Driver	07749-0010000
Attachment, 32 × 35 mm	07746-0010100
Pilot, 12 mm	07746-0040200

Install the distance collar and drive in a new left bearing using the same tools.



### Wheel center adjustment

Place the rim on the work bench.  
Place the hub with the left side down and begin lacing with new spokes.  
Adjust the hub position so that the distance from the hub right end surface to the side of rim is  $25 \pm 1$  mm ( $1.0 \pm 0.04$  in) as shown.

#### TOOL:

Spoke wrench, 4.1 × 4.5 mm	07701-0020100 (Equivalent commercially available in U.S.A.)
----------------------------	--



**TORQUE:** 2 N·m (0.2 kgf·m, 1.4 lbf·ft)

Check the rim runout (page 13-4).

Apply grease to a new dust seal lips and install it into the left wheel hub.


Install the driven sprocket, bolts and nuts and tighten them.

**TORQUE:** 32 N·m (3.3 kgf·m, 24 lbf·ft)




**INSTALLATION**


Install the left side collar into the left wheel hub.




Install the brake panel into the right wheel hub.



Place the rear wheel into the swingarm by aligning the brake panel groove with the swingarm boss.




Install the drive chain over the driven sprocket.  
Apply thin layer of grease to the axle.  
Install the axle with the right drive chain adjuster from the right side.  
Install the left drive chain adjuster and axle nut.



## REAR WHEEL/BRAKE/SUSPENSION

Install the spring onto the brake rod and the joint pin into the brake arm .  
Connect the brake rod and install the adjusting nut.

Adjust the drive chain slack (page 3-12).



## REAR BRAKE


### REMOVAL

Remove the brake panel from the rear wheel (page 13-3).

### INSPECTION


Measure the rear brake drum I.D.

**SERVICE LIMIT:** 80.5 mm (3.17 in)




Measure the brake lining thickness.

**SERVICE LIMIT:** 2.0 mm (0.08 in)



### DISASSEMBLY



Remove the brake shoes and springs.




Remove the brake arm cover if necessary.

Remove the nut, bolt and brake arm.

Remove the indicator plate, dust seal and brake cam.



**ASSEMBLY**




Apply grease to the brake cam spindle.  
Install the brake cam into the brake panel.



## REAR WHEEL/BRAKE/SUSPENSION

Apply oil to a new dust seal and install it onto the brake panel.

Install the wear indicator onto the brake cam by aligning its wide tooth with the wide groove in the brake cam.





Install the brake arm by aligning the punch marks on the arm and brake cam.

Install a new brake arm pinch bolt and nut as shown and tighten it to the specified torque.

**TORQUE:** 6 N·m (0.6 kgf·m , 4.3 lbf·ft)

Install the brake arm cover onto the arm.




Apply grease to the anchor pin and brake cam sliding surfaces.

Assemble the brake shoes and spring as shown and install them onto the brake panel.

Wipe any excess grease off the brake cam and anchor pin.

### INSTALLATION

Install the rear wheel (page 13-7).




## SHOCK ABSORBER

### REMOVAL


Support the motorcycle securely using a hoist or equivalent and raise the rear wheel off the ground.

Remove the seat (page 2-2).

Remove the shock absorber lower mounting nut and bolt.



Remove the upper mounting nut and bolt and the shock absorber.



### INSPECTION

Visually inspect the following:

- Spring for fatigue or damage
- Damper rod for bend or damage
- Damper unit for deformation or oil leaks
- Bump rubber for wear or damage
- Mounting bushings for damage

Replace the shock absorber assembly if necessary.





### INSTALLATION

Install the shock absorber into the frame and swingarm.

Install the upper and lower mounting bolts from the left side.

Install the nuts and tighten them to the specified torque.

**TORQUE:** 34 N·m (3.5 kgf·m , 25 lbf·ft)




**SWINGARM**

**REMOVAL**


- Remove the following:
- Rear wheel (page 13-3)
  - Drive chain (page 3-12)

Remove the bolts and drive chain cover.  
Remove the bolts, nuts and drive chain guard.



Remove the shock absorber lower mounting nut and bolt.

Remove the swingarm pivot nut, bolt and swingarm.




Remove the nut and bolt and the drive chain slider.



**INSPECTION**


Inspect the swingarm for wear or damage.  
Inspect the pivot bushings for wear or damage.



### INSTALLATION

Install the drive chain slider and tighten the nut.

**TORQUE:** 12 N·m (1.2 kgf·m , 9 lbf·ft)




Install the swingarm over the frame, then install the pivot bolt from the right side and the shock absorber lower mounting bolt from the left side.

Apply grease to the seating surface of the swingarm pivot nut.


Install and tighten the nuts to the specified torque.

**TORQUE: Swingarm:** 39 N·m (4.0 kgf·m , 29 lbf·ft)  
**Shock absorber:**  
34 N·m (3.5 kgf·m , 25 lbf·ft)



Install the drive chain guard and tighten the bolts.  
Install the drive chain cover and tighten the bolts.


Install the rear wheel (page 13-7).  
Install the drive chain (page 3-12).



## BRAKE PEDAL


### REMOVAL

Remove the rear brake adjusting nut.




## REAR WHEEL/BRAKE/SUSPENSION

Remove the cotter pin, joint pin and brake rod.



Unhook the brake pedal return spring from the spring holding pin.  
Remove the cotter pin, washer and brake pedal.




### INSTALLATION

Apply grease to the pivot groove and install the brake pedal.




Install the washer and a new cotter pin to secure the brake pedal.  
Install the return spring as shown.



## REAR WHEEL/BRAKE/SUSPENSION

Install the spring onto the brake rod and the joint pin into the brake arm.  
Install the rod to the brake arm with the adjusting nut.





Connect the brake rod to the pedal with the joint pin and secure it with a new cotter pin.  
Adjust the brake pedal free play (page 3-15).



# IGNITION SYSTEM

## SYSTEM DIAGRAM



# 14. IGNITION SYSTEM

SYSTEM DIAGRAM	14-0	IGNITION CONTROL MODULE	14-6
SERVICE INFORMATION	14-1	ENGINE STOP SWITCH/ IGNITION SWITCH	14-7
TROUBLESHOOTING	14-2	IGNITION TIMING	14-7
IGNITION SYSTEM INSPECTION	14-3		
IGNITION COIL	14-6		

## SERVICE INFORMATION

### GENERAL

#### ▲WARNING

*When the engine must be running to do some work, make sure the area is well-ventilated. Never run the engine in an enclosed area. The exhaust contains poisonous carbon monoxide gas that may cause loss of consciousness and lead to death. Run the engine in an open area or with an exhaust evacuation system in an enclosed area.*

- When servicing the ignition system, always follow the steps in the troubleshooting sequence on page 14-3.
- The CDI ignition system uses an electrically controlled ignition timing system. No adjustments can be made to the ignition timing.
- The ICM may be damaged if dropped. Also if the connector is disconnected when current is flowing, the excessive voltage may damage the module.
- A faulty ignition system is often related to poor connections. Check those connections before proceeding.
- Use spark plug of the correct heat range. Using spark plug with an incorrect heat range can damage the engine.
- For alternator and ignition pulse generator removal and installation, see section 10.

### SPECIFICATIONS

ITEM		SPECIFICATIONS	
Spark plug	Standard	CR6HSA (NGK)	U20FSR-U (DENSO)
	For cold climate/below 41°F/5°C	CR5HSA (NGK)	U16FSR-U (DENSO)
	For extended high speed riding	CR7HSA (NGK)	U22FSR-U (DENSO)
Spark plug gap		0.60–0.70 mm (0.024–0.028 in)	
Ignition coil peak voltage		100 V minimum	
Ignition pulse generator peak voltage		0.7 V minimum	
Alternator exciter coil peak voltage		100 V minimum	
Ignition timing ("F" mark)		27°BTDC at idle	

**14**

### TORQUE VALUES

Ignition coil mounting bolt 6 N·m (0.6 kgf·m, 4.3 lbf·ft)

### TOOLS

Peak voltage tester (U.S.A. only) or 07HGJ–0020100 (not available in U.S.A.) with commercially available digital multimeter (impedance 10 MΩ/DCV minimum)  
Peak voltage adaptor

## IGNITION SYSTEM

### TROUBLESHOOTING

Inspect the following before diagnosing the system.

- Faulty spark plug
- Loose spark plug cap or spark plug wire connections
- Water got into the spark plug cap (leaking the ignition coil secondary voltage)


#### No spark at spark plug

Unusual condition		Probable cause (Check in numerical order)
Ignition coil primary voltage	Low peak voltage	<ol style="list-style-type: none"> <li>1. Incorrect peak voltage adaptor connections (System is normal if measured voltage is over the specifications with reverse connections).</li> <li>2. The multimeter impedance is too low; 10M<math>\Omega</math>/DCV.</li> <li>3. Cranking speed is too low (operating force of the kickstarter is weak).</li> <li>4. The sampling timing of the tester and measured pulse were not synchronized (System is normal if measured voltage is over the standard voltage at least once).</li> <li>5. Poorly connected connectors or an open circuit in ignition system.</li> <li>6. Faulty exciter coil (Measure peak voltage).</li> <li>7. Faulty ignition coil.</li> <li>8. Faulty ICM (in case when above No. 1-7 are normal).</li> </ol>
	No peak voltage	<ol style="list-style-type: none"> <li>1. Incorrect peak voltage adaptor connections (System is normal if measured voltage is over the specifications with reverse connections).</li> <li>2. Short circuit in ignition switch wire or engine stop switch wire (black/white).</li> <li>3. Faulty ignition switch or engine stop switch.</li> <li>4. Loose or poorly connected ICM connectors.</li> <li>5. Open circuit or poor connection in ground wire (green) of the ICM.</li> <li>6. Faulty peak voltage adaptor.</li> <li>7. Faulty exciter coil (Measure peak voltage).</li> <li>8. Faulty ignition pulse generator (Measure peak voltage).</li> <li>9. Faulty ICM (in case when above No. 1-8 are normal).</li> </ol>
	Peak voltage is normal, but no spark jumps at plug	<ol style="list-style-type: none"> <li>1. Faulty spark plug or leaking ignition coil secondary current ampere.</li> <li>2. Faulty ignition coil.</li> </ol>
Exciter coil	Low peak voltage	<ol style="list-style-type: none"> <li>1. The multimeter impedance is too low; 10 M<math>\Omega</math>/DCV.</li> <li>2. Cranking speed is too slow (operating force of the kickstarter is weak).</li> <li>3. The sampling timing of the tester and measured pulse were not synchronized (System is normal if measured voltage is over the standard voltage at least once).</li> <li>4. Faulty exciter coil (in case when above No. 1-3 are normal).</li> </ol>
	No peak voltage	<ol style="list-style-type: none"> <li>1. Faulty peak voltage adaptor.</li> <li>2. Faulty exciter coil.</li> </ol>
Ignition pulse generator	Low peak voltage	<ol style="list-style-type: none"> <li>1. The multimeter impedance is too low; 10 M<math>\Omega</math>/DCV.</li> <li>2. Cranking speed is too slow (operating force of the kickstarter is weak).</li> <li>3. The sampling timing of the tester and measured pulse were not synchronized (System is normal if measured voltage is over the standard voltage at least once).</li> <li>4. Faulty ignition pulse generator (in case when above No. 1-3 are normal).</li> </ol>
	No peak voltage	<ol style="list-style-type: none"> <li>1. Faulty peak voltage adaptor.</li> <li>2. Faulty ignition pulse generator.</li> </ol>

## IGNITION SYSTEM INSPECTION

**NOTE:**

- If there is no spark at plug, check all connections for loose or poor contact before measuring each peak voltage.
- Use recommended digital multimeter or commercially available digital multimeter with an impedance of 10 M $\Omega$ /DCV minimum.
- The display value differs depending upon the internal impedance of the multimeter.
- If using peak voltage tester (U.S.A. only), follow the manufacturer's instructions.



Connect the peak voltage adaptor to the digital multimeter, or use the peak voltage tester (U.S.A. only).

**TOOLS:**

Peak voltage tester (U.S.A. only) or  
 Peak voltage adaptor 07HGJ-0020100  
 (not available in U.S.A.) with commercially available digital multimeter (impedance 10 M $\Omega$ /DCV minimum)


### IGNITION COIL PRIMARY PEAK VOLTAGE

**▲WARNING**

*Avoid touching the spark plug and tester probes to prevent electric shock.*

**NOTE:**

- Check all system connections before inspection. If the system is disconnected, incorrect peak voltage might be measured.
- Check cylinder compression and check that the spark plug is installed correctly.



Disconnect the spark plug cap from the spark plug. Connect a known good spark plug to the spark plug cap and ground the spark plug to the cylinder as done in a spark test.

## IGNITION SYSTEM

With the ignition coil primary wire connected, connect the peak voltage adaptor or peak voltage tester probes to the ignition coil primary wire terminal and ground.

### CONNECTION:


Black/Yellow terminal (-) - Body ground (+)

Turn the ignition switch ON and engine stop switch to "RUN".

Shift the transmission into neutral.  
Crank the engine with the kickstarter and read ignition coil primary peak voltage.

**PEAK VOLTAGE:** 100 V minimum

If the peak voltage is abnormal, follow the checks described in the troubleshooting chart (page 14-2).



## IGNITION PULSE GENERATOR PEAK VOLTAGE

### NOTE:

Check cylinder compression and check that the spark plug is installed correctly.

Remove the seat assembly (page 2-2).

Disconnect the 4P connector from the ICM.  
Connect the peak voltage adaptor or peak voltage tester probes to the connector terminals of the wire harness side.

### TOOLS:


Peak voltage tester (U.S.A. only) or  
Peak voltage adaptor 07HGJ-0020100  
(not available in U.S.A.) with commercially available digital multimeter (impedance 10 M $\Omega$ /DCV minimum)

### CONNECTION:

Blue/Yellow terminal (+) - Green (-)

Shift the transmission into neutral.  
Crank the engine with the kickstarter and read the peak voltage.

**PEAK VOLTAGE:** 0.7 V minimum




If the peak voltage measured at ICM connector is abnormal, measure the peak voltage at the pulse generator connector.

Disconnect the ignition pulse generator connector (blue/yellow) and connect the peak voltage adaptor or tester probes to the connector terminal of the ignition pulse generator side and ground.

In the same manner as at the ICM connector, measure the peak voltage and compare it to the voltage measured at the ICM connector.

- If the peak voltage measured at the ICM is abnormal and the one measured at the ignition pulse generator is normal, the wire harness has an open circuit or loose connection.
- If both peak voltages are abnormal, follow the checks described in the troubleshooting chart (page 14-2).



## ALTERNATOR EXCITER COIL PEAK VOLTAGE

### ⚠ WARNING

*Avoid touching the spark plug and tester probes to prevent electric shock.*

### NOTE:

Check cylinder compression and check that the spark plug is installed correctly.

Remove the seat assembly (page 2-2).

Disconnect the 3P and 2P connectors from the ICM. Connect the peak voltage adaptor or peak voltage tester probes to the connector terminals of the wire harness side.


### TOOLS:

Peak voltage tester (U.S.A. only) or  
 Peak voltage adaptor 07HGJ-0020100  
 (not available in U.S.A.) with commercially available digital multimeter (impedance 10 M $\Omega$ /DCV minimum)

**CONNECTION:** Black/Red terminal (+) – Green (–)

Shift the transmission into neutral.  
 Crank the engine with kickstarter and read the peak voltage.

**PEAK VOLTAGE:** 100 V minimum




## IGNITION SYSTEM

If the peak voltage measured at ICM connector is abnormal, measure the peak voltage at the alternator exciter coil connector.

Disconnect the alternator exciter coil connector (black/red) and connect the peak voltage adaptor or tester probes to the connector terminal of the exciter coil side and ground.

In the same manner as at the ICM connector, measure the peak voltage and compare it to the voltage measured at the ICM connector.

- If the peak voltage measured at the ICM is abnormal and the one measured at the alternator exciter coil is normal, the wire harness has an open circuit or loose connection.
- If both peak voltages are abnormal, follow the checks described in the troubleshooting chart (page 14-2).



## IGNITION COIL

### REMOVAL/INSTALLATION

Disconnect the spark plug cap from the plug. Disconnect the wires from the ignition coil.

Remove the bolt and ignition coil.

Installation is in the reverse order of removal.

**TORQUE:** 6 N·m (0.6 kgf·m , 4.3 lbf·ft)



## IGNITION CONTROL MODULE


### REMOVAL/INSTALLATION

Remove the seat assembly (page 2-2).

Disconnect the Ignition Control Module (ICM) connectors.

Remove the ICM from the frame.

Installation is in the reverse order of removal.




## ENGINE STOP SWITCH/ IGNITION SWITCH

### INSPECTION

Disconnect the switch connectors.

Check for continuity between the black/white and green wire terminals of the switch side connectors.



There should be continuity with the switch OFF and there should be no continuity when the engine stop switch is RUN or the ignition switch is ON.

## IGNITION TIMING

### ▲WARNING

*When the engine must be running to do some work, make sure the area is well-ventilated. Never run the engine in an enclosed area. The exhaust contains poisonous carbon monoxide gas that may cause loss of consciousness and lead to death. Run the engine in an open area or with an exhaust evacuation system in an enclosed area.*

Warm up the engine.  
Stop the engine and remove the left crankcase cover (page 10-2).

*Read the instructions for timing light operation.*

Connect the timing light to the spark plug wire.


Start the engine and let it idle.

**IDLE SPEED:** 1,700 ± 100 rpm

The ignition timing is correct if the "F" mark aligns with the index notch on the left crankcase.

Increase the engine speed by turning the throttle stop screw and make sure the "F" mark begins to move clockwise.

Install the left crankcase cover (page 10-8).



---

**MEMO**

TO: [Illegible]

FROM: [Illegible]

DATE: [Illegible]

[Illegible text]

[Illegible text]

[Illegible text]

[Illegible text]

[Illegible text]

[Illegible text]


[Illegible text]

[Illegible text]

[Illegible text]

[Illegible text]

# 15. WIRING DIAGRAM



0030Z-GEL-7000

---

MEMO

07-05-10-11-10-11




# 16. TROUBLESHOOTING

ENGINE DOES NOT START OR IS HARD TO START	16-1	POOR PERFORMANCE AT HIGH SPEED	16-4
ENGINE LACKS POWER	16-2	POOR HANDLING	16-4
POOR PERFORMANCE AT LOW AND IDLE SPEED	16-3		


## ENGINE DOES NOT START OR IS HARD TO START


### Possible cause




## TROUBLESHOOTING

### ENGINE LACKS POWER






**POOR PERFORMANCE AT LOW AND IDLE SPEED**




## TROUBLESHOOTING

### POOR PERFORMANCE AT HIGH SPEED



### POOR HANDLING



# 17. INDEX

AIR CLEANER .....	3-5
AIR CLEANER HOUSING .....	5-3
AIR SCREW ADJUSTMENT .....	5-10
BRAKE PEDAL .....	13-13
BRAKE SHOE WEAR .....	3-14
BRAKE SYSTEM .....	3-14
CABLE & HARNESS ROUTING .....	1-14
CAM CHAIN TENSIONER .....	10-4
CAMSHAFT INSTALLATION .....	7-15
CAMSHAFT REMOVAL .....	7-3
CARBURETOR ASSEMBLY .....	5-6
CARBURETOR DISASSEMBLY .....	5-5
CARBURETOR INSTALLATION .....	5-8
CARBURETOR REMOVAL .....	5-3
CLUTCH .....	9-4
CLUTCH SYSTEM .....	3-16
CRANKCASE ASSEMBLY .....	11-14
CRANKCASE BREATHER .....	5-11
CRANKCASE SEPARATION .....	11-3
CRANKSHAFT .....	11-4
CYLINDER/PISTON INSPECTION .....	8-4
CYLINDER COMPRESSION .....	7-3
CYLINDER HEAD .....	7-4
CYLINDER INSTALLATION .....	8-7
CYLINDER REMOVAL .....	8-3
DRIVE CHAIN .....	3-12
DRIVE CHAIN SLIDER .....	3-14
EMISSION CONTROL INFORMATION LABEL (Except Canada type) .....	1-18
EMISSION CONTROL SYSTEMS .....	1-17
ENGINE IDLE SPEED .....	3-11
ENGINE INSTALLATION .....	6-4
ENGINE OIL .....	3-8
ENGINE OIL CENTRIFUGAL FILTER .....	3-10
ENGINE OIL STRAINER SCREEN .....	3-10
ENGINE REMOVAL .....	6-2
ENGINE STOP SWITCH/IGNITION SWITCH .....	14-7
EXHAUST SYSTEM .....	2-4
FLYWHEEL/STATOR REMOVAL .....	10-2
FORK .....	12-12
FRONT BRAKE .....	12-10
FRONT FENDER .....	2-3
FRONT WHEEL .....	12-5
FUEL LINE .....	3-4
FUEL TANK .....	2-3
GEARSHIFT LINKAGE .....	9-14
GENERAL SAFETY .....	1-1
HANDLEBAR .....	12-3
IGNITION COIL .....	14-6
IGNITION CONTROL MODULE .....	14-6
IGNITION SYSTEM INSPECTION .....	14-3
IGNITION TIMING .....	14-7
KICKSTARTER .....	11-12
LUBRICATION & SEAL POINTS .....	1-13
LUBRICATION SYSTEM DIAGRAM .....	4-0
MAINTENANCE SCHEDULE .....	3-3
MODEL IDENTIFICATION .....	1-3
NUMBER PLATE .....	2-4
NUTS, BOLTS, FASTENERS .....	3-18
OIL PUMP .....	4-2
PISTON INSTALLATION .....	8-7
PISTON REMOVAL .....	8-3
REAR BRAKE .....	13-8
REAR FENDER .....	2-4
REAR WHEEL .....	13-3
RIGHT CRANKCASE COVER INSTALLATION .....	9-17
RIGHT CRANKCASE COVER REMOVAL .....	9-3
SEAT .....	2-2
SERVICE INFORMATION	
ALTERNATOR/CAM CHAIN TENSIONER .....	10-1
CLUTCH/GEARSHIFT LINKAGE .....	9-1
CRANKSHAFT/TRANSMISSION/ KICKSTARTER .....	11-1
CYLINDER HEAD/VALVES .....	7-1
CYLINDER/PISTON .....	8-1
ENGINE REMOVAL/INSTALLATION .....	6-1
FRAME/BODY PANELS/EXHAUST SYSTEM .....	2-1
FRONT WHEEL/BRAKE/SUSPENSION/ STEERING .....	12-1
FUEL SYSTEM .....	5-1
IGNITION SYSTEM .....	14-1
LUBRICATION SYSTEM .....	4-1
MAINTENANCE .....	3-1
REAR WHEEL/BRAKE/SUSPENSION .....	13-1
SERVICE RULES .....	1-2
SHOCK ABSORBER .....	13-10
SIDE STAND .....	2-5
SIDE STAND .....	3-16
SPARK ARRESTER .....	3-17
SPARK PLUG .....	3-6
SPECIFICATIONS .....	1-4
STATOR/FLYWHEEL INSTALLATION .....	10-6
STEERING HEAD BEARINGS .....	3-19
STEERING STEM .....	12-15
SUSPENSION .....	3-16
SWINGARM .....	13-12
SYSTEM DIAGRAM .....	14-0
THROTTLE OPERATION .....	3-4
TOOLS .....	1-12
TORQUE VALUES .....	1-10
TRANSMISSION .....	11-6
TROUBLESHOOTING	
ALTERNATOR/CAM CHAIN TENSIONER .....	10-1
CLUTCH/GEARSHIFT LINKAGE .....	9-2
CRANKSHAFT/TRANSMISSION/ KICKSTARTER .....	11-2
CYLINDER/PISTON .....	8-2
CYLINDER HEAD/VALVES .....	7-2
ENGINE DOES NOT START OR IS HARD TO START .....	16-1
ENGINE LACKS POWER .....	16-2
FRAME/BODY PANELS/EXHAUST SYSTEM .....	2-1
FRONT WHEEL/BRAKE/SUSPENSION/ STEERING .....	12-2
FUEL SYSTEM .....	5-2
IGNITION SYSTEM .....	14-2
LUBRICATION SYSTEM .....	4-1
POOR HANDLING .....	16-4
POOR PERFORMANCE AT HIGH SPEED .....	16-4
POOR PERFORMANCE AT LOW AND IDLE SPEED .....	16-3
REAR WHEEL/BRAKE/SUSPENSION .....	13-2
VALVE CLEARANCE .....	3-7
WHEELS/TIRES .....	3-18
WIRING DIAGRAM .....	15-1